

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Use Ctrl-F to search by Manufacturer or Model Number

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
360 SYSTEMS	DR600	Digital Audio Gear	G-MIX-B 1515	G-TOUR 12X17			
3M	S15	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
3M	S40	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
3M	S50	Projector	GAV-1412-R	GAV-1813-UR	GAV-DLX-1412R	GAV-PE-1412R	
3M	S55	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
3M	X40	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
3M	X45	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
3M	X50	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
3M	X55	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
3M	X65	Projector	G-TOURCARRYON				
3M	X75	Projector	GAV-1412-R	GAV-1813-UR	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYON
ACCESS	VIRUS CLASSIC	Keyboard	GK-2110				
ACCESS	VIRUS TI 61	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
ACCESS	VIRUS TI DESKTOP	Keyboard	GK-2110				
ACCESS	VIRUS TI SNOW	Digital Audio Gear	G-MIX-B 1212				
ACER	AL2016WSD	LCD/Plasma	G-TOURLCDP-2024				
ADAM	SUB10	Speaker	GPA-450-515	GPA-600	GPA-SCVR450-515		
ADAM AUDIO	SUB10 MKII	Speaker	GPA-450-515	GPA-600	GPA-SCVR450-515		
AKAI	DPS24	Amp/Cabinet	G-212A	G-TOUR AMP2430			
AKAI	MPC1000	Digital Audio Gear	G-MIX-B 1515	G-TOUR 12X17			
AKAI	MPC2000XL-MCD	Digital Audio Gear	G-MIX 17X18	G-MIX-B 1815	G-MIX-B 1818	G-MIX-B 2118	G-MIX-L 1618
AKAI	MPC2500	Digital Audio Gear	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618	G-TOUR 19X21	
AKAI	MPC4000 PLUS	Digital Audio Gear	G-MIX 19X21	G-MIX-B 2118	G-TOUR 19X21		
AKAI	MPC500	Digital Audio Gear	G-MIX-B 1212				
AKAI	MPD16	Digital Audio Gear	G-MIX-B 1212				
AKAI	MPD24	Digital Audio Gear	G-MIX-B 1515	G-MIX-L 1618	G-TOUR 12X17		
AKAI	PDP4290	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
AKAI	PDP4294	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
AKAI	PDP4298ED	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
AKAI	PDP4298ED1	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
AKG	AS16X12	Mixer	G-MIX 12X24	G-MIX-L 1224			
AKG	AS8	Mixer	G-MIX 12X24	G-MIX-L 1224			
AKG	AS8TC	Mixer	G-MIX 12X24	G-MIX-L 1224			
AKG	WMS40	Wireless System	GM-1W	GM-1WP	GM-2W		
AKIRA -NEOART	EMP 500	LCD/Plasma	G-TOURLCDP50				
AKIRA -NEOART	EMP420A/B	LCD/Plasma	G-LCD-4042	G-LCD-4647			
AKIRA -NEOART	HPT500AW	LCD/Plasma	G-TOURLCDP50				
AKIRA -NEOART	SV4202IQ	LCD/Plasma	G-LCD-4647				
ALESIS	A6	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
ALESIS	ANDROMEDA	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
ALESIS	CD TWIN LE	Digital Audio Gear	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
ALESIS	FUSION 6HD	Keyboard	GK-49	GKB-49			
ALESIS	FUSION 8HD	Keyboard	GK-288SLIM	GK-76	GKB-76	G-TOUR 88 SLIM	
ALESIS	iMULTIMIX 16USB	Mixer	G-MIX-B 2118	G-MIX-L 1622	G-MIX-L 1724	G-MIX-L 1822	
ALESIS	iMULTIMIX 8USB	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-TOUR 12X17		
ALESIS	ION	Keyboard	GK-49	GKB-49			
ALESIS	MICRON	Keyboard	GK-2110	GK-LT25W			
ALESIS	MULTIMIX 12 FIREWIRE	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618
ALESIS	MULTIMIX 12 FX	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17	
ALESIS	MULTIMIX 12 USB	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17	
ALESIS	MULTIMIX 12FXD	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17	
ALESIS	MULTIMIX 16 FIREWIRE	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-B 1818	G-MIX-B 2118	G-MIX-L 1618
ALESIS	MULTIMIX 6FX	Mixer	G-MIX-B 1212				
ALESIS	MULTIMIX 8 FW	Mixer	G-MIX-B 1212	G-MIX-B 1515			
ALESIS	MULTIMIX 8 FX	Mixer	G-MIX-B 1212	G-MIX-B 1515			
ALESIS	MULTIMIX 8 USB	Mixer	G-MIX-B 1212	G-MIX-B 1515			
ALESIS	MULTIMIX12FIREWIRE	Digital Audio Gear	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618
ALESIS	MULTIMIX16FIREWIRE	Digital Audio Gear	G-MIX 17X18	G-MIX-B 1815	G-MIX-B 1818	G-MIX-B 2118	G-MIX-L 1618
ALESIS	MULTIMIX8FIREWIRE	Digital Audio Gear	G-MIX-B 1212	G-MIX-B 1515			
ALESIS	PHOTONX25	Keyboard	GK-2110				
ALESIS	QS6.2	Keyboard	GK-249	GK-49	GKB-49		
ALESIS	QS8.2	Keyboard	GK-276R	GK-76	GKB-76	G-TOUR 76	
ALESIS	SR16	Digital Audio Gear	G-MIX-B 1212				
ALESIS	SR-16	Digital Audio Gear	G-MIX-B 1212				
ALESIS	STUDIO 24	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 19X21	
ALLEN & HEATH	PA 12	Mixer	G-MIX-12 PU	G-TOUR 12PU	G-TOUR-SLMX12		
ALLEN & HEATH	PA 12-CP	Mixer	G-MIX 19X21	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	
ALLEN & HEATH	XONE 464	Mixer	G-MIX 19X21	G-MIX-B 2020	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21
ALLEN & HEATH	ZED-12FX	Mixer	G-MIX 19X21	G-MIX-B 2020	G-MIX-L 1622	G-TOUR 19X21	
ALLEN & HEATH	ZED-14	Mixer	G-MIX 19X21	G-MIX-B 2020	G-MIX-L 1622	G-TOUR 19X21	
ALLEN & HEATH	ZED-22FX	Mixer	G-MIX 20X30	G-TOUR 20X30			
ALLEN & HEATH	ZED-24	Mixer	G-MIX 20X30	G-TOUR 20X30			
ALLEN & HEATH	ZED-R16	Mixer	G-MIX 20X30	G-TOUR 20X30			
ALTO AUDIO	AMX 100	Mixer	G-MIX-B 1212				
ALTO AUDIO	AMX 100 FX	Mixer	G-MIX-B 1212				
ALTO AUDIO	L-12	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 19X21	
ALTO AUDIO	L-16	Mixer	G-MIX 20X25	G-MIX-B 2020	G-TOUR 20X25		
ALTO AUDIO	L-20	Mixer	G-MIX 20X25	G-MIX-B 2020	G-TOUR 20X25		
ALTO AUDIO	L-6	Mixer	G-MIX-B 1212				
ALTO AUDIO	L-8	Mixer	G-MIX-B 1212	G-MIX-B 1515			
ALTO AUDIO	PM-12 DRAGONFLY	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618	G-TOUR 19X21	
ALTO AUDIO	S-12	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-L 1618	G-TOUR 12X17	
ALTO AUDIO	S-16	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 19X21	
ALTO AUDIO	S-6	Mixer	G-MIX-B 1212				

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
ALTO AUDIO	S-8	Mixer	G-MIX-B 1212	G-MIX-B 1515			
AMERICAN AUDIO	CDI 300	CD/DVD Player	G-TOUR CD-13X17				
AMERICAN AUDIO	CDI 300 MP3	CD/DVD Player	G-TOUR CD-13X17				
AMERICAN AUDIO	CDI 500	CD/DVD Player	G-TOUR CD-13X17				
AMERICAN AUDIO	CDI 500 MP3	CD/DVD Player	G-TOUR CD-13X17				
AMERICAN AUDIO	CDS-1	CD/DVD Player	G-TOUR CD-9X12				
AMERICAN AUDIO	CK-1000	Mixer	G-MIX-B 1815	G-MIX-L 1618	G-MIX-L 1622		
AMERICAN AUDIO	CK-800	Mixer	G-MIX-B 1815	G-MIX-L 1618	G-MIX-L 1622		
AMERICAN AUDIO	DLS-15	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
AMERICAN AUDIO	DLS-15P	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
AMERICAN AUDIO	HTD 4.5	Turntable	GDJ-1500	GDJ-2500	G-TOUR T-TABLE		
AMERICAN AUDIO	MX-1400	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618
AMERICAN AUDIO	PSW-15	Speaker	G-SUB2225-24BAG				
AMERICAN AUDIO	PSW-15P	Speaker	G-SUB2225-24BAG				
AMERICAN AUDIO	PXI-10P	Speaker	GPA-600				
AMERICAN AUDIO	PXI-12P	Speaker	GPA-450-515	GPA-600	GPA-E15	GPA-SCVR450-515	
AMERICAN AUDIO	PXI-15P	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
AMERICAN AUDIO	Q-221	Mixer	G-MIX-B 1515	G-MIX-L 1618	G-TOUR 12X17		
AMERICAN AUDIO	Q-2221/SX	Turntable	G-TOUR T-TABLE				
AMERICAN AUDIO	Q-2221/X	Turntable	G-TOUR T-TABLE				
AMERICAN AUDIO	Q-D1	Mixer	G-MIX-B 1212				
AMERICAN AUDIO	Q-D1 MKII	Mixer	G-MIX-B 1212				
AMERICAN AUDIO	Q-D3	Mixer	G-MIX-B 1515	G-MIX-L 1618	G-TOUR 12X17		
AMERICAN AUDIO	Q-D5	Mixer	G-MIX-B 1515	G-TOUR 12X17			
AMERICAN AUDIO	Q-D5 MKII	Mixer	G-MIX-B 1515	G-TOUR 12X17			
AMERICAN AUDIO	Q-D5B	Mixer	G-MIX-B 1515	G-TOUR 12X17			
AMERICAN AUDIO	Q-D6	Mixer	G-MIX-B 1515	G-TOUR 12X17			
AMERICAN AUDIO	Q-MX2BPM	Mixer	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
AMERICAN AUDIO	TTD-2500MKII	Turntable	GDJ-1500	GDJ-2500	G-TOUR T-TABLE		
AMERICAN AUDIO	XDM-221	Mixer	G-MIX-B 1212				
AMERICAN AUDIO	XDM-241	Mixer	G-MIX-B 1212				
AMPEG	B-500 DR	Digital Audio Gear	G-MIX 19X21	G-MIX-B 2020	G-MIX-L 1622	G-TOUR 19X21	
AMPEG	J20	Amp/Cabinet	G-112A				
AMPEG	SVT450H	Amp/Cabinet	G-212-ROTO				
AMPEG	SVTCL	Amp/Cabinet	G-212-ROTO				
AMPEG	SVT-CT	Amp/Cabinet	G-212-ROTO				
AMPEG	SVTVR	Amp/Cabinet	G-212-ROTO				
ANCHOR AUDIO	BWKII	Mixer	G-TOUR 12X17				
APEX	LD1919	LCD/Plasma	G-TOURLCDP-2023				
APPLE	20 CINEMA DISPLAY	LCD/Plasma	G-TOURLCDP-2023				
APPLE	M8893ZM/A	LCD/Plasma	G-TOURLCDP-2023				
APPLE	MACBOOK 13"	Laptop	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
APPLE	MACBOOK AIR	Laptop	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
APPLE	MACBOOK PRO 15"	Laptop	GAV-1813-UR	G-TOURCARRYON			
APPLE	MACBOOK PRO 17"	Laptop	GAV-1813-UR	G-TOURCARRYON			
ART	TUBE MP PROJECT SERIES	Digital Audio Gear	G-MIX-B 1212				
ARTURIA	ANALOG FACTORY	Keyboard	GK-2110				
ASHLY	LX308B	Digital Audio Gear	GK-2110	G-MIX 12X24	G-MIX-L 1224		
ASK	M1	Projector	G-TOURCARRYON				
ASK	PROXIMA M2+	Projector	G-TOURCARRYON				
AUDIO TECHNICA	ATM341A	Mixer	G-MIX-B 1212				
AUDIO TECHNICA	ATPL120	Turntable	GDJ-2500	G-TOUR T-TABLE			
AUDIO TECHNICA	ATW-2192-TH	Wireless System	GM-1W	GM-1WP	GM-2W	GM-5W	
AUDIO TECHNICA	ATW-251	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
AUDIO TECHNICA	ATW-251/H92-TH	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
AUDIO TECHNICA	ATW-252	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
AUDIO TECHNICA	ATW-3192A-TH	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
AUDIO TECHNICA	ATW-701	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
AUDIO TECHNICA	ATW-701/H92-TH	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
AUDIO-TECHNICA	ATM351	Mixer	G-MIX-B 1815	G-TOUR 12X17			
Audio-Technica	ATW2120	Wireless System	GM-1W	GM-1WP	GM-2W	GM-5W	
Audio-Technica	ATW-2129	Wireless System	GM-1W	GM-1WP	GM-2W	GM-5W	
Audio-Technica	ATW3131A	Wireless System	GM-1W	GM-1WP	GM-2W		
Audio-Technica	ATW3141A	Wireless System	GM-1W	GM-1WP	GM-2W		
Audio-Technica	ATW-3192A	Wireless System	GM-1W	GM-1WP	GM-2W		
Audio-Technica	ATW-701 700 Series	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
Audio-Technica	ATW-702	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
B-52	AT-100	Amp/Cabinet	G-TOUR AMP HEAD				
B-52	AT112	Amp/Cabinet	G-112A	G-TOUR AMP2226			
B-52	AT212	Amp/Cabinet	G-TOUR AMP HEAD				
B-52	LG10012S	Amp/Cabinet	G-212A	G-TOUR AMP2430			
B-52	LG-100A	Amp/Cabinet	G-212-ROTO	G-901			
B-52	LG200AS	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
B-52	LG7512	Amp/Cabinet	G-112A	G-212A	G-TOUR AMP2226	G-TOUR AMP2430	
B-52	ST-100A	Amp/Cabinet	G-TOUR AMP HEAD				
B-52	ST6012	Amp/Cabinet	G-212A	G-TOUR AMP2430			
B-52	ST60A	Amp/Cabinet	G-TOUR AMP HEAD				
BEHRINGER	B1220 PRO	Speaker	GPA-700	GPA-777			
BEHRINGER	B212	Speaker	GPA-450-515	GPA-600	GPA-E15	GPA-SCVR450-515	
BEHRINGER	B212A	Speaker	GPA-450-515	GPA-600	GPA-E15	GPA-SCVR450-515	
BEHRINGER	B215	Speaker	GPA-700	GPA-777			
BEHRINGER	B215A	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
BEHRINGER	BCD2000	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-L 1618	G-TOUR 12X17	
BEHRINGER	BCF2000	Digital Audio Gear	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17
BEHRINGER	BCR2000	Digital Audio Gear	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
BEHRINGER	BEDDX3216	Mixer	G-MIX 20X25	G-MIX-B 2519	G-TOUR 20X25		
BEHRINGER	DDX3216	Mixer	G-MIX 20X25	G-MIX-B 2519	G-TOUR 20X25		
BEHRINGER	DJX400	Mixer	G-TOUR 12X17				
BEHRINGER	DJX700	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618
BEHRINGER	DX052	Mixer	G-MIX-B 1515	G-MIX-L 1618	G-TOUR 12X17		
BEHRINGER	DX-626	Mixer	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
BEHRINGER	E1220	Speaker	GPA-700	GPA-777			
BEHRINGER	E1520	Speaker	GPA-700	GPA-777			
BEHRINGER	EURORACK UB1202	Mixer	G-MIX-B 1212				
BEHRINGER	EURORACK UB2442FX PRO	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21	
BEHRINGER	EURORACK UB802	Mixer	G-MIX-B 1212				
BEHRINGER	K1800FX	Amp/Cabinet	G-112A				
BEHRINGER	K900FX	Amp/Cabinet	G-112A				
BEHRINGER	KX1200	Amp/Cabinet	G-TOUR AMP HEAD				
BEHRINGER	LC2412	Digital Audio Gear	G-MIX 12X24	G-MIX-B 1815	G-MIX-L 1618	G-MIX-L 1622	
BEHRINGER	LX112	Amp/Cabinet	G-112A	G-TOUR AMP2226			
BEHRINGER	MX1604A	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17
BEHRINGER	MX1804X	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618	G-TOUR 19X21	
BEHRINGER	MX2004A	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618	G-TOUR 19X21	
BEHRINGER	MX2442A	Mixer	G-MIX 20X30	G-TOUR 20X30			
BEHRINGER	MX3282A	Mixer	G-MIX 22X46				
BEHRINGER	MX602A	Mixer	G-MIX-B 1212				
BEHRINGER	MX802A	Mixer	G-MIX-B 1212	G-MIX-B 1515			
BEHRINGER	MX882	Digital Audio Gear	GK-2110	G-MIX 12X24	G-MIX-L 1224		
BEHRINGER	MXB1002	Mixer	G-MIX-B 1212	G-TOUR 12X17			
BEHRINGER	PMH1000	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618	G-TOUR 19X21	
BEHRINGER	PMH2000	Mixer	GPA-720				
BEHRINGER	PMH3000	Mixer	G-MIX 19X21	G-MIX-B 2020	G-TOUR 19X21		
BEHRINGER	PMH5000	Mixer	G-MIX 20X25	G-MIX 20X30	G-TOUR 20X25		
BEHRINGER	PMH518M	Mixer	G-MIX-B 1815	G-MIX-L 1224			
BEHRINGER	PMH660M	Mixer	GPA-720				
BEHRINGER	PMH880S	Mixer	GPA-720				
BEHRINGER	PMP1000	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618	G-TOUR 19X21	
BEHRINGER	PMP1280S	Mixer	GPA-720				
BEHRINGER	PMP2000	Mixer	GPA-720				
BEHRINGER	PMP3000	Mixer	G-MIX 19X21	G-MIX-B 2020	G-TOUR 19X21		
BEHRINGER	PMP5000	Mixer	G-MIX 20X25	G-MIX 20X30	G-TOUR 20X25		
BEHRINGER	PMX 2000	Mixer	GPA-720				
BEHRINGER	SL2442FX-PRO	Mixer	G-MIX 20X30	G-TOUR 20X30			
BEHRINGER	SX2442FX	Mixer	G-MIX 20X30	G-TOUR 20X30			
BEHRINGER	UB1002	Mixer	G-MIX-B 1212				
BEHRINGER	UB1202	Mixer	G-MIX-B 1212				
BEHRINGER	UB1224FX-PRO	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618
BEHRINGER	UB1622FX-PRO	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-L 1618	G-TOUR 12X17	
BEHRINGER	UB1832FX-PRO	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 19X21	
BEHRINGER	UB2222FX-PRO	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 19X21	
BEHRINGER	UB2442FX-PRO	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21	
BEHRINGER	UB802	Mixer	G-MIX-B 1212				
BEHRINGER	UBB1002	Mixer	G-MIX-B 1212	G-TOUR 12X17			
BEHRINGER	ULTRACOUSTIC ACX1800	Amp/Cabinet	G-112A	G-TOUR AMP2226			
BEHRINGER	ULTRACOUSTIC ACX900	Amp/Cabinet	G-112A	G-TOUR AMP2226			
BEHRINGER	ULTRASTACK BG412F	Amp/Cabinet	G-TOUR-4X12-CAB				
BEHRINGER	ULTRASTACK BG412H	Amp/Cabinet	G-TOUR-4X12-CAB				
BEHRINGER	ULTRASTACK BG412S	Amp/Cabinet	G-TOUR-4X12-CAB				
BEHRINGER	V-AMPIRE LX1200H	Amp/Cabinet	G-212-ROTO	G-901			
BEHRINGER	VMX100	Mixer	G-MIX-B 1212				
BEHRINGER	VMX1000	Mixer	G-MIX 12X24	G-MIX-L 1224			
BEHRINGER	VMX200	Mixer	G-MIX-B 1212				
BEHRINGER	VMX300	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-TOUR 12X17		
BEHRINGER	V-TONE GMX1200H	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
BEHRINGER	V-TONE GMX210	Amp/Cabinet	G-112A	G-TOUR AMP2226			
BEHRINGER	V-TONE GMX212	Amp/Cabinet	G-212A	G-TOUR AMP2430			
BEHRINGER	X V-AMP	Digital Audio Gear	G-MIX-B 1212				
BEHRINGER	XENYX 1002	Mixer	G-MIX-B 1212				
BEHRINGER	XENYX 1002 FX	Mixer	G-MIX-B 1212				
BEHRINGER	XENYX 1202	Mixer	G-MIX-B 1212				
BEHRINGER	XENYX 1202 FX	Mixer	G-MIX-B 1212				
BEHRINGER	XENYX 1204	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-TOUR 12X17		
BEHRINGER	XENYX 1204FX	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-TOUR 12X17		
BEHRINGER	XENYX 1222 FX	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618
BEHRINGER	XENYX 1622 FX	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-L 1618	G-TOUR 12X17	
BEHRINGER	XENYX 1832 FX	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 19X21	
BEHRINGER	XENYX 2222FX	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 19X21	
BEHRINGER	XENYX 2442 FX	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21	
BEHRINGER	XENYX 802	Mixer	G-MIX-B 1212				
BELKIN	TUNE STUDIO	Mixer	G-MIX 17X18	G-MIX-B 1815			
BEN Q	FP-202W	LCD/Plasma	G-TOURLCDP-2023				
BENCHMARK	DAC1C	Digital Audio Gear	G-MIX-B 1212				
BENQ	PB2140	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONP
BENQ	PB2240	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONP
BENQ	PB6100	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONP	
BENQ	PB6200	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONP	
BENQ	PB6-200	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONP	
BENQ	PB7110	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONP
BENQ	PB7200	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONP

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
BENQ	PB7210	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONP
BENQ	PB7230	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONP
BENQ	PB8220	Projector	GAV-1412-R	GAV-1813-UR	GAV-DLX-1412R	GAV-PE-1412R	
BENQ	PE5120	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONP	
BENQ	PE7700	Projector	G-TOURCARRYONP				
BENQ	SP870	Projector	G-TOURCARRYONP				
BENQ / ACER	859	LCD/Plasma	G-LCD-4042		G-TOURLCD-3743T		
BENQ / ACER	46W1	LCD/Plasma	G-LCD-4647	G-TOURLCDP50			
BOGNER	ALCHEMIST HEAD	Amp/Cabinet	G-212-ROTO	G-901			
BOGNER	CAB 1120	Amp/Cabinet	G-TOUR AMP2226				
BOGNER	CUSTOM SHOP DUENDE HEAD	Amp/Cabinet	G-212-ROTO	G-901			
BOGNER	CUSTOM SHOP ECSTASY 101	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
BOGNER	CUSTOM SHOP SHIVA HEAD	Amp/Cabinet	G-212-ROTO	G-901			
BONGER	DUENDE110	Amp/Cabinet	G-212A	G-TOUR AMP2430			
BONGER	DUENDE112-15	Amp/Cabinet	G-212A	G-TOUR AMP2430			
BONGER	SHIVA112RV	Amp/Cabinet	G-212A	G-TOUR AMP2430			
BOSE	B1	Speaker	GPA-600				
BOSS	AD-3	Digital Audio Gear	G-MIX-B 1212				
BOSS	AD-8	Digital Audio Gear	G-MIX-B 1212				
BOSS	BR1180CD	Digital Audio Gear	GK-2110	G-MIX 12X24	G-MIX-B 1815	G-MIX-L 1224	G-MIX-L 1622
BOSS	BR1200CD	Digital Audio Gear	G-MIX 12X24	G-MIX-L 1224	G-MIX-L 1622	G-MIX-L 1724	
BOSS	BR1600CD	Digital Audio Gear	G-MIX 19X21	G-MIX-B 2118	G-MIX-L 1622	G-TOUR 19X21	
BOSS	BR-600	Digital Audio Gear	G-MIX-B 1212				
BOSS	BR-864	Digital Audio Gear	G-MIX-B 1515	G-TOUR 12X17			
BOSS	BR-900CD	Digital Audio Gear	G-MIX-B 1515	G-TOUR 12X17			
BOSS	DD-20	Digital Audio Gear	G-MIX-B 1212				
BOSS	DR. 880	Digital Audio Gear	G-MIX-B 1212	G-MIX-B 1515			
BOSS	DR-3	Digital Audio Gear	G-MIX-B 1212				
BOSS	DR-670	Digital Audio Gear	G-MIX-B 1212				
BOSS	GS-10	Digital Audio Gear	G-MIX-B 1515	G-MIX-B 1815	G-TOUR 12X17		
BOSS	GT-10	Digital Audio Gear	GK-2110	G-MIX 12X24	G-MIX-L 1224	G-MIX-L 1622	
BOSS	GT-10B	Digital Audio Gear	GK-2110	G-MIX 12X24	G-MIX-L 1224	G-MIX-L 1622	
BOSS	GT-6	Digital Audio Gear	GK-2110	GK-LT25W	G-MIX 12X24	G-MIX-L 1224	G-MIX-L 1622
BOSS	GT-6B	Digital Audio Gear	GK-2110	GK-LT25W	G-MIX 12X24	G-MIX-L 1224	G-MIX-L 1622
BOSS	GT-8	Digital Audio Gear	GK-2110	GK-LT25W	G-MIX 12X24	G-MIX-L 1224	G-MIX-L 1622
BOSS	ME-20	Digital Audio Gear	G-MIX-B 1212	G-TOUR 12X17			
BOSS	ME-50	Digital Audio Gear	G-TOUR 12X17				
BOSS	ME-50B	Digital Audio Gear	G-TOUR 12X17				
BOSS	ME-70	Digital Audio Gear	G-MIX-B 1515	G-MIX-B 1815	G-TOUR 12X17		
BOSS	RE-20	Digital Audio Gear	G-MIX-B 1212				
BOSS	SP-505	Digital Audio Gear	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
BOXLIGHT	7200	LCD/Plasma	G-TOURLCD-3743T				
BOXLIGHT	PD4600	LCD/Plasma	G-LCD-4647	G-TOURLCDP50			
BUDDA	SUPERDRIVE 18	Amp/Cabinet	G-TOUR AMP2226				
CANNON	LV-S3	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONP
CANON	LV-5220	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R		
CANON	LV-7220	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R		
CANON	LV-7225	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R		
CANON	LV-7230	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R		
CANON	LV-S4	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONP
CANON	LV-X4	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
CANON	REALIS SX-50	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R		
CARL MARTIN	QUATTRO	Digital Audio Gear	G-TOUR 12X17				
CARVIN	LM15A	Speaker	GPA-700	GPA-777			
CASIO	140	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
CASIO	140S	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
CASIO	CDP-100	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
CASIO	CTK3000	Keyboard	GK-49	GK-61	GKB-61	GKC-1540	
CASIO	CTK4000	Keyboard	GK-49	GK-61	GKB-61	GKC-1540	
CASIO	CTK496	Keyboard	GK-49	GK-61	GKB-61	GKC-1540	
CASIO	CTK5000	Keyboard	GK-49	GK-61	GKB-61	GKC-1540	
CASIO	CTK-691	Keyboard	GK-61	GKB-61	GKC-1540		
CASIO	CTK710	Keyboard	GK-49	GK-61	GKB-61	GKC-1540	
CASIO	CTK800	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
CASIO	CTK810	Keyboard	GK-61	GKB-61	GKC-1540		
CASIO	CTK900	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
CASIO	LK100	Keyboard	GK-4212	GK-49	GK-61	GKB-61	GKC-1540
CASIO	LK-200S	Keyboard	GK-49	GK-61	GKB-61	GKC-1540	
CASIO	LK-220	Keyboard	GK-49	GK-61	GKB-61	GKC-1540	
CASIO	LK-300TV	Keyboard	GK-61	GKB-61	GKC-1540		
CASIO	P70	Keyboard	GK-288R	GK-288SLIM-XLNG	GK-88	GKB-88	G-TOUR 88
CASIO	P70S	Keyboard	GK-288R	GK-288SLIM-XLNG	GK-88	GKB-88	G-TOUR 88
CASIO	PS20	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
CASIO	PX-100	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
CASIO	PX110	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
CASIO	PX-120	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
CASIO	PX-200	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
CASIO	PX-300	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
CASIO	PX-320	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
CASIO	PX500L	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
CASIO	PX575R	Keyboard	GKB-88				
CASIO	WK-110	Keyboard	GK-276-DEEP	GK-276R	GK-76	GKB-76	G-TOUR 76
CASIO	WK-1300	Keyboard	GK-276-DEEP				
CASIO	WK-200	Keyboard	GK-276-DEEP	GK-76	GKB-76		
CASIO	WK3200	Keyboard	GK-276-DEEP				

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
CASIO	WK-3300	Keyboard	GK-276-DEEP				
CASIO	WK3700	Keyboard	GK-276-DEEP				
CASIO	WK-3800	Keyboard	GK-276-DEEP				
CASIO	WK500	Keyboard	GK-276-DEEP	GK-76	GKB-76		
CASIO	WK8000	Keyboard	GKC-1648				
CASIO	XJ-350	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONF
CASIO	XJ-360	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONF
CASIO	XJ-560	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONF
CASIO	YPG-225	Keyboard	GK-276-DEEP	GK-276R	GK-76	GKB-76	G-TOUR 76
CASIO	YPG-525	Keyboard	GK-288R	GK-88	GKB-88	G-TOUR 88	
CASIO	YPG-625	Keyboard	GK-288R	GKC-1648	G-TOUR 88		
CERWIN VEGA	CLS-15S	Speaker	G-SUB2225-24BAG				
CERWIN VEGA	CVA-118	Speaker	G-SUB2225-24BAG				
CERWIN VEGA	HT2510	Speaker	GPA-600				
CERWIN VEGA	HTS15A	Speaker	G-SUB2225-24BAG				
CERWIN VEGA	LW10	Speaker	GPA-600				
CERWIN VEGA	PSX-36	Speaker	G-SUB2225-24BAG				
CERWIN VEGA	SUB15 MKII	Speaker	G-SUB2225-24BAG				
CHAMPION	42CV1	LCD/Plasma	G-LCD-4642	G-LCD-4647	G-TOURLCD-3743T		
CLAVIA	G2X	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
CLAVIA	NORD ELECTRO 2 61	Keyboard	GK-249	GK-49	GKB-49		
CLAVIA	NORD ELECTRO 2 73	Keyboard	GK-261R	G-TOUR 61			
CLAVIA	NORD ELECTRO 61	Keyboard	GK-249	GK-49	GKB-49		
CLAVIA	NORD ELECTRO 73	Keyboard	GK-261R	G-TOUR 61			
CLAVIA	NORD LEAD 2	Keyboard	GK-49	GKB-49			
CLAVIA	NORD LEAD 2X	Keyboard	GK-249	GK-49	GKB-49		
CLAVIA	NORD LEAD 3	Keyboard	GK-249	GK-49	GKB-49		
CLAVIA	NORD MODULAR G2X	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
CLAVIA	NORD STAGE 88	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
CLAVIA	RACK3	Digital Audio Gear	GK-2110	G-MIX 12X24	G-MIX-L 1224		
CME	UF5	Keyboard	GK-49	GKB-49			
CME	UF50	Keyboard	GK-49	GKB-49			
CME	UF6	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
CME	UF60	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
CME	UF7	Keyboard	GK-276R	GK-76	GKB-76	G-TOUR 76	
CME	UF70	Keyboard	GK-276R	GK-76	GKB-76	G-TOUR 76	
CME	UF8	Keyboard	GK-288R	GK-288SLIM-XLNG	GK-88	GKB-88	G-TOUR 88
CME	UF80	Keyboard	GK-288R	GK-288SLIM-XLNG	GK-88	GKB-88	G-TOUR 88
COMMUNITY	SBS12	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
COOPER SOUND	SYSTEM 6	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618	G-TOUR 19X21	
COOPER SOUND	SYSTEM 8	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618	G-TOUR 19X21	
CORTEX	DMIX-300	Mixer	G-MIX 12X24	G-MIX-L 1224	G-MIX-L 1622		
CORTEX	DMIX-600	Mixer	G-MIX 12X24	G-MIX-L 1224	G-MIX-L 1622		
CORTEX	HDDT-5000	Turntable	GDJ-1500	GDJ-2500	G-TOUR T-TABLE		
CRATE	BT220H	Amp/Cabinet	G-112A	G-212-ROTO			
CRATE	BV120HB	Amp/Cabinet	G-TOUR AMP HEAD				
CRATE	BV150HB	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
CRATE	BV215S	Amp/Cabinet	G-TOUR-4X12-CAB				
CRATE	BV300HB	Amp/Cabinet	G-TOUR AMP HEAD				
CRATE	BV412RVB	Amp/Cabinet	G-TOUR-4X12-CAB				
CRATE	BV412SL	Amp/Cabinet	G-TOUR-4X12-CAB				
CRATE	BV412ST	Amp/Cabinet	G-TOUR-4X12-CAB				
CRATE	BV412SVB	Amp/Cabinet	G-TOUR-4X12-CAB				
CRATE	CA125DG	Amp/Cabinet	G-112A	G-TOUR AMP2226			
CRATE	FW120	Amp/Cabinet	G-TOUR AMP2430				
CRATE	FW120H	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
CRATE	FW412A	Amp/Cabinet	G-TOUR-4X12-CAB				
CRATE	FW412B	Amp/Cabinet	G-TOUR-4X12-CAB				
CRATE	GLX1200H	Amp/Cabinet	G-212-ROTO	G-901			
CRATE	GLX212	Amp/Cabinet	G-TOUR AMP2430				
CRATE	GLX412SL	Amp/Cabinet	G-TOUR-4X12-CAB				
CRATE	GLX412ST	Amp/Cabinet	G-TOUR-4X12-CAB				
CRATE	GLX50	Amp/Cabinet	G-112A				
CRATE	GLX65	Amp/Cabinet	G-TOUR AMP2226				
CRATE	GT112SL	Amp/Cabinet	G-212A	G-TOUR AMP2430			
CRATE	GT1200H	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
CRATE	GT212	Amp/Cabinet	G-212A	G-TOUR AMP2430			
CRATE	GT30	Amp/Cabinet	G-112A				
CRATE	GT3500H	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
CRATE	GT412SL	Amp/Cabinet	G-TOUR-4X12-CAB				
CRATE	GT65	Amp/Cabinet	G-112A				
CRATE	GTX212	Amp/Cabinet	G-212A	G-TOUR AMP2430			
CRATE	GTX65	Amp/Cabinet	G-112A				
CRATE	PX700DLX	Mixer	GPA-720				
CRATE	TX50DBE	Amp/Cabinet	G-112-ROTO				
CRATE	V18-112	Amp/Cabinet	G-112A	G-TOUR AMP2226			
CRATE	V18-212	Amp/Cabinet	G-212A	G-TOUR AMP2430			
CRATE	V212T	Amp/Cabinet	G-212A	G-TOUR AMP2430			
CRATE	V3112	Amp/Cabinet	G-112A	G-TOUR AMP2226			
CRATE	V-33	Amp/Cabinet	G-212A	G-TOUR AMP2430			
CRATE	VFX5112	Amp/Cabinet	G-112A	G-TOUR AMP2226			
CRATE	VFX5212	Amp/Cabinet	G-212A	G-TOUR AMP2430			
CRATE	VTX200S	Amp/Cabinet	G-212A	G-TOUR AMP2430			
CRATE	VTX212B	Amp/Cabinet	G-212A	G-TOUR AMP2430			
CRATE	VTX350 HEAD	Amp/Cabinet	G-901	G-TOUR AMP HEAD			

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
CRATE	VTX65B	Amp/Cabinet	G-112A	G-TOUR AMP2226			
CRATE	XT120R	Amp/Cabinet	G-212A	G-TOUR AMP2430			
CREATIVE-LABS	PROKEYS PD-MIDI	Keyboard	GK-2110	GK-LT25W			
CREST AUDIO	XR20	Mixer	G-MIX 19X21	G-MIX-B 2020	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21
CREST AUDIO	XR24	Mixer	G-MIX 19X21	G-MIX-B 2020	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21
CREST AUDIO	XRM	Mixer	G-MIX 19X21	G-MIX-B 2020	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21
DAEWOO	DP-42SM	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
DAEWOO	DSP-4210GM	LCD/Plasma	G-LCD-4042	G-LCD-4647			
DAEWOO	PD-42S20W	LCD/Plasma	G-LCD-4647				
DAEWOO	PPM-42S3	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
DAVE SMITH	EVOLVER DESKTOP	Digital Audio Gear	G-MIX-B 1212				
DAVE SMITH	POLY EVOLVER KEYBOARD	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
DAVE SMITH	POLY EVOLVER RACK	Digital Audio Gear	GK-2110	G-MIX 12X24	G-MIX-L 1224		
DAVE SMITH	PROPHET 08	Keyboard	GK-249	GK-49	GKB-49		
DELL	INSPIRON 1200	Laptop	GAV-1412-R	GAV-1813-UR	GAV-DLX-1412R	GAV-PE-1412R	
DELL	INSPIRON 1300	Laptop	GAV-1813-UR	G-TOURCARRYON			
DELL	INSPIRON 6000	Laptop	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYON
DELL	INSPIRON 9400	Laptop	GAV-1813-UR	G-TOURCARRYON			
DELL	INSPIRON B120	Laptop	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYON
DELL	INSPIRON E1505	Laptop	GAV-1813-UR	G-TOURCARRYON			
DELL	INSPIRON E1705	Laptop	GAV-1813-UR	G-TOURCARRYON			
DELL	LATITUDE C610	Laptop	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
DELL	SP2008WFP	LCD/Plasma	G-TOURLCDP-2023				
DELL	W4200	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
DELL	XPS M1210	Laptop	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
DELL	XPS M1710	Laptop	GAV-1813-UR	G-TOURCARRYON			
DELPHI	DD42 EVOLUTION	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
DELPHI	DD42 PANACHE	LCD/Plasma	G-LCD-4647				
DELPHI	PRO42 EVOLUTION	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
DELPHI	PRO42 PANACHE	LCD/Plasma	G-LCD-4647				
DELTA LAB	DGFX1	Digital Audio Gear	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17	
DENON	DN-HS5500	Turntable	GDJ-2500	G-TOUR T-TABLE			
DENON	DN-S1000	CD/DVD Player	G-TOUR CD-9X12				
DENON	DN-S3000 DN-S3000	CD/DVD Player	G-TOUR CD-13X17				
DENON	DN-X100	Mixer	G-MIX-B 1212				
DENON	DN-X1500	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618
DENON	DN-X1500S	Mixer	G-MIX 12X24	G-MIX-L 1224			
DENON	DN-X300	Mixer	G-MIX-B 1515	G-TOUR 12X17			
DENON	DP29F	Turntable	GDJ-1500	GDJ-2500	G-TOUR T-TABLE		
DENON	DP300F	Turntable	GDJ-1500	GDJ-2500			
DIGIDESIGN	COMMAND 8	Digital Audio Gear	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21	
DIGIDESIGN	DIGI002	Digital Audio Gear	G-MIX 19X21	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	
DIGIDESIGN	DIGI-003	Digital Audio Gear	G-MIX 20X25	G-MIX-B 2020	G-TOUR 20X25		
DIGIDESIGN	MBOX2	Digital Audio Gear	G-MIX-B 1212				
DIGIDESIGN	MBOX2 PRO	Digital Audio Gear	G-MIX-B 1212	G-MIX-B 1515			
DIGIDESIGN	OO2R	Digital Audio Gear	G-MIX-B 2118	G-MIX-L 1622	G-MIX-L 1724	G-MIX-L 1822	
DIGITECH	GNX1	Digital Audio Gear	G-MIX-B 1515	G-TOUR 12X17			
DIGITECH	GNX2	Digital Audio Gear	GK-2110	G-MIX 12X24			
DIGITECH	GNX3	Digital Audio Gear	GK-2110	GK-LT25W	G-MIX 12X24	G-MIX-L 1224	
DIGITECH	GNX3000	Digital Audio Gear	GK-2110	G-MIX 12X24	G-MIX-B 1815	G-MIX-L 1224	G-MIX-L 1622
DIGITECH	GNX4	Digital Audio Gear	GK-2110	GK-LT25W	G-MIX 12X24	G-MIX-L 1224	
DIGITECH	RP-1000	Digital Audio Gear	GK-2110	GK-LT25W	G-MIX 12X24	G-MIX-L 1224	
DIGITECH	RP150	Digital Audio Gear	G-MIX-B 1212				
DIGITECH	RP250	Digital Audio Gear	G-MIX-B 1212				
DIGITECH	RP350	Digital Audio Gear	G-TOUR 12X17				
DIGITECH	RP500	Digital Audio Gear	GK-2110	GK-LT25W	G-MIX 12X24	G-MIX-L 1224	
DIGITECH	RP90	Digital Audio Gear	G-MIX-B 1212				
DIGITECH	VL2	Digital Audio Gear	G-MIX-B 1212				
DIGITECH	VL4	Digital Audio Gear	G-TOUR 12X17				
DIGITECH	VOCAL 300	Digital Audio Gear	G-TOUR 12X17				
DYNEX	DX-L32-10A	LCD/Plasma	G-TOURLCDP-2632				
DYNEX	DX-L42-10A	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
EAW	FR129Z	Speaker	GPA-450-515	GPA-600	GPA-700	GPA-777	GPA-SCVR450-515
EAW	FR153Z	Speaker	G-SUB2225-24BAG				
EAW	SB120ZP	Speaker	GPA-450-515	GPA-600	GPA-777	GPA-E15	GPA-SCVR450-515
EAW	SB150Z	Speaker	G-SUB2225-24BAG				
EAW	SB180ZP	Speaker	G-SUB2225-24BAG				
EAW	SM109Z	Speaker	GPA-600				
EAW	SM129Z	Speaker	GPA-700				
EAW	SM159Z	Speaker	G-SUB2225-24BAG				
EDIROL	FA-66	Digital Audio Gear	G-MIX-B 1212				
EDIROL	M-100FX	Digital Audio Gear	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
EDIROL	M10DX	Digital Audio Gear	G-MIX-B 1212				
EDIROL	M-10DX	Mixer	G-MIX-B 1212				
EDIROL	M-10E	Digital Audio Gear	G-MIX-B 1212				
EDIROL	M16DX	Digital Audio Gear	G-TOUR 12X17				
EDIROL	M-16DX	Mixer	G-TOUR 12X17				
EDIROL	PCR-1	Keyboard	GK-2110				
EDIROL	PCR500	Keyboard	GK-249	GK-49	GKB-49		
EDIROL	PCR800	Keyboard	GK-4212				
EDIROL	PCR-M1	Keyboard	GK-2110				
EDIROL	PCR-M50	Keyboard	GK-249	GK-49	GKB-49		
EDIROL	PCR-M80	Keyboard	GK-4212				
EDIROL	R-44	Digital Audio Gear	G-MIX-B 1212				
EDIROL	UA101	Digital Audio Gear	G-MIX-B 1212				

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
EDIROL	UA-700	Digital Audio Gear	G-MIX-B 1212				
EDIROL	UM-550	Digital Audio Gear	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
EDIROL	UR-80	Digital Audio Gear	G-MIX-B 1815	G-TOUR 12X17			
EDIROL	V-4	Digital Audio Gear	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
EIKI	LC-XB28	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
EIKI	PLD-42UE	LCD/Plasma	G-TOURLCD-3743T				
EIKI	PLD-42XU	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
EIZO	CE240W	LCD/Plasma	G-TOURLCDP-2023				
EIZO	CG210	LCD/Plasma	G-TOURLCDP-2023				
EIZO	P5070	LCD/Plasma	G-TOURLCDP50				
EIZO	P5071	LCD/Plasma	G-TOURLCDP50				
ELECTRO HARMONIX	XO HOLY STAIN	Digital Audio Gear	G-MIX-B 1212				
ELECTRO VOICE	ELIMINATOR MONITOR	Speaker	GPA-700				
ELECTRO VOICE	FORCE I 12"	Speaker	GPA-450-515	GPA-600	GPA-E15	GPA-SCVR450-515	
ELECTRO VOICE	SB112	Speaker	GPA-450-515	GPA-600	GPA-700	GPA-777	GPA-SCVR450-515
ELECTRO VOICE	SBA760	Speaker	G-SUB2225-24BAG				
ELECTRO VOICE	SX100	Speaker	GPA-450-515	GPA-600	GPA-700	GPA-777	GPA-SCVR450-515
ELECTRO VOICE	SX250	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
ELECTROGRAPH	DTS42	LCD/Plasma	G-LCD-4042	G-LCD-4647			
ELECTROGRAPH	DTS42DD	LCD/Plasma	G-TOURLCD-3743T				
ELECTROGRAPH	E4203DD	LCD/Plasma	G-TOURLCD-3743T				
Electro-Voice	RE2	Wireless System	GM-1W	GM-1WP	GM-2W	GM-5W	
Electro-Voice	RE2 Handheld	Wireless System	GM-1W	GM-1WP	GM-2W	GM-5W	
EMES	AMBER	Speaker	GPA-600				
EMU	0404 USB	Digital Audio Gear	G-MIX-B 1212				
E-MU	X BOARD 61	Keyboard	GK-4212	GK-49			
E-MU	XBOARD 25	Keyboard	GK-2110				
E-MU	XBOARD 49	Keyboard	GK-249	GKB-49			
ENVISION	A42W64	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
EPIPHONE	BLUES CUSTOM 30	Amp/Cabinet	G-212A	G-TOUR AMP2430			
EPIPHONE	SO CAL	Amp/Cabinet	G-212-ROTO				
EPIPHONE	SO CAL 412SL	Amp/Cabinet	G-TOUR-4X12-CAB				
EPSON	730	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYON
EPSON	760	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYON
EPSON	61P	Projector	G-TOURCARRYON				
EPSON	730C	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYON
EPSON	73C	Projector	GAV-1412-R	GAV-1813-UR	GAV-DLX-1412R	GAV-PE-1412R	
EPSON	81P	Projector	G-TOURCARRYON				
EPSON	820P	Projector	G-TOURCARRYON				
EPSON	821P	Projector	G-TOURCARRYON				
EPSON	835P	Projector	G-TOURCARRYON				
EPSON	POWERLITE 732C	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYON
EPSON	POWERLITE 737C	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYON
EPSON	POWERLITE 740C	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYON
EPSON	POWERLITE 745C	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYON
EPSON	S1	Projector	G-TOURCARRYON				
EPSON	S3	Projector	GAV-1412-R	GAV-1813-UR	GAV-DLX-1412R	GAV-PE-1412R	
FBT	JOLLY SUB12A	Speaker	G-SUB2225-24BAG				
FBT	JOLLY12RA	Speaker	GPA-700	GPA-777			
FBT	MAXX 2	Speaker	GPA-450-515	GPA-600	GPA-E15	GPA-SCVR450-515	
FBT	MAXX 4	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
FBT	MAXX9SA	Speaker	G-SUB2225-24BAG				
FBT	VERVE 18S	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-E15	GPA-SCVR450-515
FENDER	57 AMP LTD	Amp/Cabinet	G-112A				
FENDER	57 DELUXE	Amp/Cabinet	G-112A				
FENDER	57 TWIN	Amp/Cabinet	G-212A	G-TOUR AMP2226	G-TOUR AMP2430		
FENDER	63 FENDER REVERB	Amp/Cabinet	G-112-ROTO				
FENDER	65 DELUXE REVERB	Amp/Cabinet	G-112A	G-TOUR AMP2226			
FENDER	65 PRINCETON REVERB	Amp/Cabinet	G-112A	G-112-ROTO			
FENDER	65 TWIN REVERB	Amp/Cabinet	G-212A	G-TOUR AMP2430			
FENDER	ACOUSTASONIC JR.	Amp/Cabinet	G-112A	G-TOUR AMP2226			
FENDER	BASSMAN 300	Amp/Cabinet	G-212-ROTO				
FENDER	BLONDE BLUES JUNIOR	Amp/Cabinet	G-112-ROTO				
FENDER	BLONDE HOT ROD DELUXE	Amp/Cabinet	G-112A	G-TOUR AMP2226			
FENDER	BLUES DELUXE	Amp/Cabinet	G-112A	G-TOUR AMP2226			
FENDER	BLUES JR	Amp/Cabinet	G-112-ROTO				
FENDER	CYBER TWIN	Amp/Cabinet	G-TOUR AMP2430				
FENDER	DELUXE 900	Amp/Cabinet	G-112A	G-TOUR AMP2226			
FENDER	DUAL PROFESSIONAL	Amp/Cabinet	G-212A	G-TOUR AMP2430			
FENDER	FM 100H	Amp/Cabinet	G-901				
FENDER	FM 212R	Amp/Cabinet	G-212A	G-TOUR AMP2226	G-TOUR AMP2430		
FENDER	FM210R	Amp/Cabinet	G-112A	G-112-ROTO	G-212-ROTO		
FENDER	FM212 DSP	Amp/Cabinet	G-212A	G-TOUR AMP2430			
FENDER	FM412 SL	Amp/Cabinet	G-TOUR-4X12-CAB				
FENDER	HOT ROD DELUXE	Amp/Cabinet	G-112A	G-TOUR AMP2226			
FENDER	HOT ROD DEVILLE 212	Amp/Cabinet	G-212A	G-TOUR AMP2226	G-TOUR AMP2430		
FENDER	MH-412	Amp/Cabinet	G-TOUR-4X12-CAB				
FENDER	MH500	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
FENDER	PROSONIC 412	Amp/Cabinet	G-TOUR-4X12-CAB				
FENDER	ROC PRO 700	Amp/Cabinet	G-112A	G-TOUR AMP2226			
FENDER	STAGE 1000	Amp/Cabinet	G-112A	G-TOUR AMP2226			
FENDER	STAGE 1600	Amp/Cabinet	G-212A	G-TOUR AMP2430			
FENDER	SUPER SONIC HEAD	Amp/Cabinet	G-901				
FENDER	SUPER-SONIC 112	Amp/Cabinet	G-TOUR AMP2226				
FENDER	SUPER-SONIC 412	Amp/Cabinet	G-TOUR-4X12-CAB				

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
FENDER	TONE MASTER 412	Amp/Cabinet	G-TOUR-4X12-CAB				
FENDER	TWIN AMP	Amp/Cabinet	G-TOUR AMP2430				
FENDER	ULTIMATE CHORUS	Amp/Cabinet	G-212A	G-TOUR AMP2430			
FENDER	VIBRO KING	Amp/Cabinet	G-212A	G-TOUR AMP2430			
FENDER	VIBRO KING 212	Amp/Cabinet	G-212A	G-TOUR AMP2226	G-TOUR AMP2430		
FENDER	VIBRO KING 3 10	Amp/Cabinet	G-212A	G-TOUR AMP2430			
FENDER	VIBROLUX REVERB	Amp/Cabinet	G-112A	G-212A	G-TOUR AMP2226	G-TOUR AMP2430	
FOCUSRITE	SAFFIRE	Digital Audio Gear	G-MIX-B 1212				
FOSTEX	FR2	Digital Audio Gear	G-MIX-B 1212				
FOSTEX	FR-2	Digital Audio Gear	G-MIX-B 1212				
FOSTEX	FR2TC	Digital Audio Gear	G-MIX-B 1212				
FOSTEX	LR-16	Mixer	G-MIX 20X25	G-MIX-B 2519	G-TOUR 20X25		
FOSTEX	MR-16HD	Digital Audio Gear	G-MIX 19X21	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	
FOSTEX	MR-16HD/CD	Digital Audio Gear	G-MIX 19X21	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	
FOSTEX	MR-8	Digital Audio Gear	G-MIX-B 1212	G-TOUR 12X17			
FOSTEX	MR8 MKII	Digital Audio Gear	G-MIX-B 1212	G-TOUR 12X17			
FOSTEX	MR-8HD	Digital Audio Gear	G-MIX-B 1515	G-MIX-L 1618	G-TOUR 12X17		
FOSTEX	MR8HDCD	Digital Audio Gear	G-MIX-B 1515	G-MIX-L 1618	G-TOUR 12X17		
FOSTEX	VF160	Digital Audio Gear	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 19X21	
FOSTEX	VF160EX	Digital Audio Gear	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 19X21	
FOSTEX	VF80	Digital Audio Gear	G-TOUR 12X17				
FOSTEX	VF80EX	Digital Audio Gear	G-TOUR 12X17				
FOSTEX	X12	Digital Audio Gear	G-MIX-B 1212				
FRONTIER DESIGN	ALPHA TRACK	Mixer	G-MIX-B 1212				
FUJITSU	P42HHA10	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
FUJITSU	P42VHA10	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
FUJITSU	P50XHA10	LCD/Plasma	G-TOURLCDP50				
FUJITSU	PDS-4201	LCD/Plasma	G-TOURLCD-3743T				
FUJITSU	PDS-4203	LCD/Plasma	G-TOURLCD-3743T				
FUJITSU	PDS-4204	LCD/Plasma	G-TOURLCD-3743T				
FUJITSU	PDS-4207	LCD/Plasma	G-TOURLCD-3743T				
FUJITSU	PDS-4208	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
FUJITSU	PDS-4209	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
FUJITSU	PDS-4210	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
FUJITSU	PDS-4211	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
FUJITSU	PDS-4212	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
FUJITSU	PDS-4213	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
FUJITSU	PDS-4214	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
FUJITSU	PDS-4221	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
FUJITSU	PDS-4222	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
FUJITSU	PDS-4233	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
FUJITSU	PDS-5001	LCD/Plasma	G-TOURLCDP50				
Galaxy	AS-ALS-4	Wireless System	GM-1W	GM-1WP	GM-2W		
GATEWAY	42 ED & 42 HD	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
GATEWAY	50 ED & 50 HD	LCD/Plasma	G-TOURLCDP50				
GATEWAY	FHD2400	LCD/Plasma	G-TOURLCDP-2024				
GATEWAY	GTW-P42M102	LCD/Plasma	G-LCD-4042	G-LCD-4647			
GATEWAY	GTW-P42M103	LCD/Plasma	G-LCD-4042	G-LCD-4647			
GATEWAY	GTW-P46M103	LCD/Plasma	G-TOURLCDP50				
GEMINI	CDJ SERIES	CD/DVD Player	G-TOUR CD-13X17	G-TOUR CD-9X12			
GEMINI	CDJ-202	CD/DVD Player	G-TOUR CD-13X17				
GEMINI	CFX-30	CD/DVD Player	G-TOUR CD-13X17	G-TOUR CD-9X12			
GEMINI	DJ-USB TURNTABLE	Turntable	GDJ-2500	G-TOUR T-TABLE			
GEMINI	GT-USB TURNTABLE	Turntable	GDJ-2500	G-TOUR T-TABLE			
GEMINI	ICDJ	CD/DVD Player	G-TOUR CD-13X17	G-TOUR CD-9X12			
GEMINI	iTRAX	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618
GEMINI	MM SERIES	Mixer	G-MIX 12X24	G-MIX-L 1224			
GEMINI	MPX-30	CD/DVD Player	G-TOUR CD-13X17	G-TOUR CD-9X12			
GEMINI	PDM SERIES	Mixer	G-MIX 12X24	G-MIX-L 1224			
GEMINI	PMX SERIES	Mixer	G-MIX-B 1212	G-MIX-B 1515			
GEMINI	PS SERIES	Mixer	G-MIX-B 1212	G-MIX-B 1515			
GEMINI SOUND	GX350	Speaker	GPA-700				
GENELEC	7070A	Speaker	G-SUB2225-24BAG				
GENELEC	7270A	Speaker	G-SUB2225-24BAG				
GROOVE TUBES	SFXSSMKII	Amp/Cabinet	G-112-ROTO				
HAIER	HL47E	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
HAMMOND	XK-1	Keyboard	GK-276R	GK-76	GKB-76	G-TOUR 76	
HAMMOND	XK-2	Keyboard	GK-276-DEEP	GK-276R	GK-76	GKB-76	G-TOUR 76
HAMMOND	XK-3	Keyboard	GK-276-DEEP	GK-276R	GK-76	GKB-76	G-TOUR 76
HAMMOND	XM2	Digital Audio Gear	G-TOUR 12X17				
HEWLET-PCKRD	PPL-4245N	LCD/Plasma	G-LCD-4042	G-LCD-4647			
HITACHI	401XU	LCD/Plasma	G-LCD-4042				
HITACHI	402HDE	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
HITACHI	402HDU	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
HITACHI	4120HDU	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
HITACHI	42PMA500E	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
HITACHI	CMP4201U	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
HITACHI	CMP4202U	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
HITACHI	CMP4211U	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
HITACHI	CMP-5000	LCD/Plasma	G-TOURLCDP50				
HITACHI	CP-RS55	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
HITACHI	CP-S235W	Projector	GAV-1412-R	GAV-1813-UR	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYON
HITACHI	CP-S318	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
HITACHI	CP-S335	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
HITACHI	CP-S420	Projector	G-TOURCARRYON				

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
HITACHI	CP-X275	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONF
HITACHI	CP-X340	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
HITACHI	CP-X345	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
HITACHI	CP-X401	Projector	GAV-1412-R	GAV-1813-UR	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONF
HITACHI	CP-X430	Projector	G-TOURCARRYON				
HITACHI	CP-X443	Projector	GAV-1412-R	GAV-1813-UR	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONF
HITACHI	CP-X445W	Projector	GAV-1412-R	GAV-1813-UR	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONF
HOHNER	NOVA II 48	Accordion	GW-ACC-1514				
HP	LP2465	LCD/Plasma	G-TOURLCDP-2023				
HUGHES & KETTNER	ALEX LIFESON SIGNATURE	Amp/Cabinet	G-TOUR AMP HEAD				
HUGHES & KETTNER	CC412A	Amp/Cabinet	G-TOUR-4X12-CAB				
HUGHES & KETTNER	DUOTONE	Amp/Cabinet	G-TOUR AMP HEAD				
HUGHES & KETTNER	MATRIX 100	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
HUGHES & KETTNER	PURETONE	Amp/Cabinet	G-212-ROTO	G-901			
HUGHES & KETTNER	SWITCHBLADE 100 2X12	Amp/Cabinet	G-212A	G-TOUR AMP2226	G-TOUR AMP2430		
HUGHES & KETTNER	SWITCHBLADE 100 HEAD	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
HUGHES & KETTNER	SWITCHBLADE 50	Amp/Cabinet	G-TOUR AMP2226				
HUGHES & KETTNER	TRIAMP MKII	Amp/Cabinet	G-TOUR AMP HEAD				
HUGHES & KETTNER	WARP X	Amp/Cabinet	G-901				
IBANEZ	IS412C	Amp/Cabinet	G-TOUR-4X12-CAB				
IBANEZ	TB100H	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
IBANEZ	TBX150H	Amp/Cabinet	G-212-ROTO	G-901			
IBANEZ	TBX150R	Amp/Cabinet	G-212A	G-TOUR AMP2430			
IBANEZ	TBX65R	Amp/Cabinet	G-112A				
INFOCUS	IN24	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R		
INFOCUS	LP 530	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
INFOCUS	LP-120	Projector	G-TOURCARRYON				
INFOCUS	LP600	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONF
INFOCUS	LP70	Projector	G-TOURCARRYON				
INFOCUS	LP-70	Projector	G-TOURCARRYON				
INSIGNIA	NS-L42Q-10A	LCD/Plasma	G-LCD-4042	G-LCD-4647			
INSIGNIA	NS-LCD32-09	LCD/Plasma	G-TOURLCDP-2632				
INSIGNIA	NS-LCD37-09	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T			
INSIGNIA	NS-LCD47HD-09	LCD/Plasma	G-LCD-4647	G-TOURLCDP50			
INSIGNIA	NS-P42Q10A	LCD/Plasma	G-LCD-4042	G-LCD-4647			
INTER-M	A120	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618		
INTER-M	A60	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618		
INTER-M	CA 8320	Mixer	GPA-720				
INTER-M	MX1243	Mixer	G-MIX-L 1622	G-MIX-L 1822			
INTER-M	PA1000B	Mixer	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
INTER-M	PA1000BR	Mixer	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
INTER-M	PA2000	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618		
INTER-M	PA4000	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618		
INTER-M	PA920	Mixer	G-MIX-B 1212	G-TOUR 12X17			
INTER-M	PA935	Mixer	G-MIX-B 1212	G-TOUR 12X17			
INTER-M	PAM120	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 19X21	
INTER-M	PAM60	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 19X21	
INTER-M	PAMCDA	Mixer	G-MIX-B 1212				
INTER-M	PAMD	Mixer	G-MIX-B 1212				
INTER-M	PMC-05 PRO D	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17	
INTER-M	RMX1426	Mixer	G-MIX-L 1622	G-MIX-L 1822			
INTER-M	SMX812	Mixer	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
JAMO	C 80 SUB	Speaker	GPA-600				
JAMO	D 7SUB	Speaker	G-SUB2225-24BAG				
JAZZKAT	TWINKAT 210	Amp/Cabinet	G-112A	G-112-ROTO	G-212-ROTO		
JBL	EON10 G2	Speaker	GPA-600				
JBL	EON305	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
JBL	EON315	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
JBL	EON510	Speaker	GPA-600				
JBL	EON515	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
JBL	EON518S	Speaker	G-SUB2225-24BAG				
JBL	JRX112M	Speaker	GPA-450-515	GPA-600	GPA-777	GPA-E15	GPA-SCVR450-515
JBL	JRX118S	Speaker	G-SUB2225-24BAG				
JBL	MP418S	Speaker	G-SUB2225-24BAG				
JBL	MRX512	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-E15	GPA-SCVR450-515
JBL	PRX512M	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-E15	GPA-SCVR450-515
JBL	PRX518S	Speaker	G-SUB2225-24BAG				
JBL	SRX712M	Speaker	GPA-450-515	GPA-600	GPA-E15	GPA-SCVR450-515	
JBL	SRX715	Speaker	GPA-700	GPA-777			
JBL	VP7210	Speaker	GPA-600				
JBL	VP7212M	Speaker	GPA-450-515	GPA-600	GPA-700	GPA-777	GPA-SCVR450-515
JBL	VRX915M	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
JBL	VRX932LA	Speaker	GPA-450-515	GPA-600	GPA-E15	GPA-SCVR450-515	
JBL	VRX932LAP	Speaker	GPA-700	GPA-777			
JOHNSON	JM150	Amp/Cabinet	G-212A	G-TOUR AMP2430			
JOHNSON	JM250H	Amp/Cabinet	G-TOUR AMP HEAD				
JOHNSON	JM60	Amp/Cabinet	G-112A	G-TOUR AMP2226			
JOHNSON	JT50	Amp/Cabinet	G-112A	G-TOUR AMP2226			
JVC	GD-V4200PZW	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
JVC	GD-V4210PZW	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
JVC	GD-V4211PCE	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
JVC	GD-V425PZW	LCD/Plasma	G-TOURLCD-3743T				
JVC	GD-V500PZU	LCD/Plasma	G-TOURLCDP50				
JVC	GD-V501U	LCD/Plasma	G-TOURLCDP50				
JVC	GM-P420UG	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
JVC	GM-V42UG	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
JVC	LT-47X788	LCD/Plasma	G-LCD-4647				
JVC	PD-42DV2	LCD/Plasma	G-TOURLCDP50				
JVC	PD-42V475	LCD/Plasma	G-LCD-4042	G-LCD-4647			
JVC	PD-42WV74	LCD/Plasma	G-TOURLCDP50				
JVC	PD-42WV84	LCD/Plasma	G-TOURLCDP50				
JVC	PD-42WX84	LCD/Plasma	G-TOURLCDP50				
KAWAI	EP3Kawai	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
KONKA	KDL32AT23U	LCD/Plasma	G-TOURLCD-3743T				
KORG	AX10A	Digital Audio Gear	G-MIX-B 1212	G-TOUR 12X17			
KORG	AX10B	Digital Audio Gear	G-MIX-B 1212	G-TOUR 12X17			
KORG	AX10G	Digital Audio Gear	G-MIX-B 1212	G-TOUR 12X17			
KORG	AX1500G	Digital Audio Gear	GK-2110	G-TOUR 12X17			
KORG	AX3000G	Digital Audio Gear	GK-2110	GK-LT25W	G-MIX 12X24	G-MIX-L 1224	
KORG	CR-4	Digital Audio Gear	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618		
KORG	CX3	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
KORG	D1200 MKII	Digital Audio Gear	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17		
KORG	D1600	Digital Audio Gear	G-MIX 19X21	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	
KORG	D1600 MKII	Digital Audio Gear	G-MIX 19X21	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	
KORG	D16XD	Amp/Cabinet	G-212A	G-TOUR AMP2430			
KORG	D3200	Digital Audio Gear	G-MIX 20X25	G-MIX-B 2519	G-MIX-L 1622	G-MIX-L 1822	G-TOUR 20X25
KORG	D32XD	Amp/Cabinet	G-212A	G-TOUR AMP2430			
KORG	D888	Digital Audio Gear	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618
KORG	EMX1	Digital Audio Gear	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17	
KORG	ESX1	Digital Audio Gear	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17	
KORG	K61P	Keyboard	GK-4212				
KORG	KARMA	Keyboard	GK-261R	G-TOUR 61			
KORG	KORG M1	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
KORG	M3 73	Keyboard	GK-276-DEEP	GK-276R	GK-76	GKB-76	G-TOUR 76
KORG	M3 88	Keyboard	GK-288R	GK-88	GKB-88	GKC-1648	G-TOUR 88
KORG	M3-61	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
KORG	M50-61	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
KORG	M50-88	Keyboard	GK-288SLIM-XLNG	GK-88	GKB-88		
KORG	MICROKONTROL	Keyboard	GK-2110	GK-LT25W			
KORG	MICROKORG	Keyboard	GK-2110	GK-LT25W			
KORG	MR-1000	Digital Audio Gear	G-MIX-B 1212				
KORG	OASYS 76	Keyboard	GK-276-DEEP				
KORG	OASYS 88	Keyboard	GK-288R	GKC-1648	G-TOUR 88		
KORG	PA1X PRO	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
KORG	PA1X PRO ELITE	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
KORG	PA50	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
KORG	PA-588	Keyboard	GK-288R	G-TOUR 88			
KORG	PADKONTROL	Digital Audio Gear	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
KORG	PAD-KONTROL	Digital Audio Gear	G-MIX-B 1515	G-TOUR 12X17			
KORG	R3	Keyboard	GK-LT25W				
KORG	SP-200	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
KORG	SP-250	Keyboard	GK-276R	GK-76	GKB-76	G-TOUR 76	
KORG	SP-300	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
KORG	SP-500	Keyboard	GK-276R	GK-76	GKB-76	G-TOUR 76	
KORG	TR61	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
KORG	TR76	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
KORG	TR88	Keyboard	GK-288R	GK-288SLIM-XLNG	GK-88	GKB-88	G-TOUR 88
KORG	TRITON EXTREME 61	Keyboard	GK-261R	G-TOUR 61			
KORG	TRITON EXTREME 76	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
KORG	TRITON EXTREME 88	Keyboard	GK-288R	GK-88	GKB-88	G-TOUR 88	
KORG	TRITON LE 61	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
KORG	TRITON LE 76	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
KORG	TRITON LE 88	Keyboard	GK-288R	GK-288SLIM-XLNG	GK-88	GKB-88	G-TOUR 88
KORG	TRITON STUDIO 61	Keyboard	GK-261R	G-TOUR 61			
KORG	TRITON STUDIO 88	Keyboard	GK-288R	GKC-1648	G-TOUR 88		
KORG	TRITON STUDIO 76	Keyboard	GK-88	GKB-88			
KORG	X-50	Keyboard	GK-4212	GK-49			
KORG	X5D	Keyboard	GK-249	GK-49	GKB-49		
KORG	ZERO 4	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618	G-TOUR 12X17
KORG	ZERO 8	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 19X21	
KURZWEIL	K2600	Keyboard	GK-276-DEEP	GK-276R	GK-76	GKB-76	G-TOUR 76
KURZWEIL	K2600S	Keyboard	GK-276-DEEP	GK-276R	GK-76	GKB-76	G-TOUR 76
KURZWEIL	K2600X	Keyboard	GK-288R	GK-88	GKB-88	GKC-1648	G-TOUR 88
KURZWEIL	K2600XS	Keyboard	GK-288R	GK-88	GKB-88	GKC-1648	G-TOUR 88
KURZWEIL	K2661	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
KURZWEIL	PC161	Keyboard	GK-4212	GK-49	GK-61	GKB-61	GKC-1540
KURZWEIL	PC1SE	Keyboard	GK-276R	GK-76	GKB-76	G-TOUR 76	
KURZWEIL	PC-1X	Keyboard	GK-288R	GK-288SLIM-XLNG	GK-88	GKB-88	G-TOUR 88
KURZWEIL	PC-1XL	Keyboard	GK-288R	GK-288SLIM-XLNG	GK-88	GKB-88	G-TOUR 88
KURZWEIL	PC2X	Keyboard	GK-288R	GK-288SLIM-XLNG	GK-88	GKB-88	G-TOUR 88
KURZWEIL	PC3	Keyboard	GK-288R	GK-288SLIM-XLNG	GK-88	GKB-88	G-TOUR 88
KURZWEIL	PC3X	Keyboard	GK-288R	GK-288SLIM-XLNG	GK-88	GKB-88	G-TOUR 88
KURZWEIL	SP2	Keyboard	GK-288R	GK-288SLIM-XLNG	GK-88	GKB-88	G-TOUR 88
KURZWEIL	SP3X	Keyboard	GK-288R	GK-288SLIM-XLNG	GK-88	GKB-88	G-TOUR 88
KURZWEIL	SP-76	Keyboard	GK-276R	GK-76	GKB-76	G-TOUR 76	
KURZWEIL	SP-88	Keyboard	GK-288SLIM	GK-288SLIM-XLNG	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM
KURZWEIL	SP-88X	Keyboard	GK-288R	GK-288SLIM-XLNG	GK-88	GKB-88	G-TOUR 88
KUSTOM	KPC12	Speaker	GPA-450-515	GPA-600	GPA-700	GPA-777	GPA-SCVR450-515
KUSTOM	KPC12M	Speaker	GPA-450-515	GPA-600	GPA-700	GPA-777	GPA-SCVR450-515
KUSTOM	KPC15	Speaker	GPA-700				

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
KUSTOM	KPC15M	Speaker	GPA-700				
KUSTOM	KPM7250T	Mixer	GPA-720				
KUSTOM	KPM8420	Mixer	GPA-720				
KUSTOM	KPM8420T	Mixer	GPA-720				
L-ACOUSTICS	SB15P	Speaker	G-SUB2225-24BAG				
LEXICON	ALPHA	Digital Audio Gear	G-MIX-B 1212				
LEXICON	LAMBDA	Digital Audio Gear	G-MIX-B 1212				
LEXICON	OMEGA	Digital Audio Gear	G-MIX-B 1212				
LG	22LG30	LCD/Plasma	G-TOURLCDP-2023				
LG	32LC5DC	LCD/Plasma	G-TOURLCDP-2632				
LG	32LG70	LCD/Plasma	G-TOURLCDP-2632				
LG	32LH40	LCD/Plasma	G-TOURLCDP-2632				
LG	37LC-7D	LCD/Plasma	G-LCD-4042				
LG	37LH30	LCD/Plasma	G-LCD-4042				
LG	42LG50	LCD/Plasma	G-LCD-4042	G-LCD-4647			
LG	42LG70	LCD/Plasma	G-LCD-4042	G-LCD-4647			
LG	42LH30	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
LG	42LH40	LCD/Plasma	G-LCD-4042	G-LCD-4647			
LG	42PC3DV	LCD/Plasma	G-LCD-4647	G-TOURLCDP50			
LG	42PC5D	LCD/Plasma	G-LCD-4042	G-LCD-4647			
LG	42PQ30C	LCD/Plasma	G-LCD-4042	G-LCD-4647			
LG	47LG50	LCD/Plasma	G-LCD-4647	G-TOURLCDP50			
LG	47LG60	LCD/Plasma	G-TOURLCDP50				
LG	47LG70	LCD/Plasma	G-TOURLCDP50				
LG	47LG90	LCD/Plasma	G-TOURLCDP50				
LG	47LH30	LCD/Plasma	G-LCD-4647	G-TOURLCDP50			
LG	47LH40	LCD/Plasma	G-LCD-4647	G-TOURLCDP50			
LG	47LH50	LCD/Plasma	G-TOURLCDP50				
LG	50PM1M	LCD/Plasma	G-TOURLCDP50				
LG	50PQ30C	LCD/Plasma	G-TOURLCDP50				
LG	50PS60C	LCD/Plasma	G-TOURLCDP50				
LG	52LB5D	LCD/Plasma	G-TOURLCDLIFT52				
LG	52LG50	LCD/Plasma	G-TOURLCDLIFT52				
LG	60PS60C	LCD/Plasma	G-TOURLCDP60				
LG	M3702C-BA	LCD/Plasma	G-TOURLCD-3743T				
LG	M4210N-B21	LCD/Plasma	G-TOURLCD-3743T				
LG	M4212C-BA	LCD/Plasma	G-TOURLCD-3743T				
LG	M4212T-BA	LCD/Plasma	G-TOURLCD-3743T				
LG	M4224C-BA	LCD/Plasma	G-TOURLCD-3743T				
LG	M4714C-BA	LCD/Plasma	G-LCD-4647				
LG	M4714T-BA	LCD/Plasma	G-LCD-4647				
LG	M5201C-BA	LCD/Plasma	G-TOURLCDP60				
LG	MU-40PA10B	LCD/Plasma	G-LCD-4042				
LG	MU-42PM11	LCD/Plasma	G-LCD-4647				
LG	MU-42PZ11B	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
LG	MU-42PZ15B	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
LG	MU50PM10	LCD/Plasma	G-TOURLCDP50				
LG	MU60P	LCD/Plasma	G-TOURLCDP60				
LINE 6	212S CAB	Amp/Cabinet	G-212A	G-TOUR AMP2430			
LINE 6	412CB	Amp/Cabinet	G-TOUR-4X12-CAB				
LINE 6	412S CAB	Amp/Cabinet	G-TOUR-4X12-CAB				
LINE 6	AX2	Amp/Cabinet	G-212A	G-TOUR AMP2430			
LINE 6	BASS FLOOR POD	Digital Audio Gear	G-MIX-B 1515	G-TOUR 12X17			
LINE 6	BASS POD	Digital Audio Gear	G-MIX-B 1212				
LINE 6	BASS POD PRO	Digital Audio Gear	GK-2110	G-MIX 12X24	G-MIX-L 1224		
LINE 6	BASS POD XT LIVE	Digital Audio Gear	GK-2110	G-MIX 12X24	G-MIX-L 1224	G-MIX-L 1622	
LINE 6	BASS POD-PRO	Digital Audio Gear	GK-2110	G-MIX 12X24	G-MIX-L 1224		
LINE 6	BASS XT PRO	Digital Audio Gear	GK-2110	G-MIX 12X24	G-MIX-L 1224		
LINE 6	BOD	Digital Audio Gear	G-MIX-B 1212	G-TOUR 12X17			
LINE 6	BOD XT PRO	Digital Audio Gear	GK-2110	G-MIX 12X24	G-MIX-L 1224		
LINE 6	CLASSIC 112 (FLEX 3)	Amp/Cabinet	G-TOUR AMP2226				
LINE 6	CLASSIC PLUS (FLEX 3)	Amp/Cabinet	G-TOUR AMP2226				
LINE 6	DL4	Digital Audio Gear	G-MIX-B 1212				
LINE 6	DM4	Digital Audio Gear	G-MIX-B 1212				
LINE 6	DUOVERB 212	Amp/Cabinet	G-212A	G-TOUR AMP2430			
LINE 6	DUOVERB HEAD	Amp/Cabinet	G-212-ROTO	G-901			
LINE 6	FBC	Digital Audio Gear	GK-2110	G-MIX 12X24	G-MIX-L 1224		
LINE 6	FLEXTONE II	Amp/Cabinet	G-112A	G-TOUR AMP2226			
LINE 6	FLEXTONE II HD	Amp/Cabinet	G-901				
LINE 6	FLEXTONE II PLUS	Amp/Cabinet	G-112A	G-TOUR AMP2226			
LINE 6	FLEXTONE II XL	Amp/Cabinet	G-212A	G-TOUR AMP2430			
LINE 6	FLEXTONE III 112	Amp/Cabinet	G-112A	G-TOUR AMP2226			
LINE 6	FLEXTONE III PLUS 112	Amp/Cabinet	G-112A	G-TOUR AMP2226			
LINE 6	FLEXTONE III XL	Amp/Cabinet	G-212A	G-TOUR AMP2430			
LINE 6	FLOOR POD	Digital Audio Gear	GK-2110	GK-LT25W	G-MIX 12X24	G-MIX-L 1224	G-MIX-L 1622
LINE 6	FM4	Digital Audio Gear	G-MIX-B 1212				
LINE 6	HD 147	Amp/Cabinet	G-901				
LINE 6	LD15	Amp/Cabinet	G-112A	G-112-ROTO			
LINE 6	M 13 STOMPBOX	Digital Audio Gear	G-MIX 17X18	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618	G-TOUR 12X17
LINE 6	MM4	Digital Audio Gear	G-MIX-B 1212				
LINE 6	POD 2.0	Digital Audio Gear	G-MIX-B 1212				
LINE 6	POD PRO	Digital Audio Gear	GK-2110	G-MIX 12X24	G-MIX-L 1224		
LINE 6	POD PRO XT	Digital Audio Gear	GK-2110	G-MIX 12X24	G-MIX-L 1224		
LINE 6	POD STUDIO UX2	Digital Audio Gear	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
LINE 6	POD X3	Digital Audio Gear	G-MIX-B 1212				

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
LINE 6	POD X3 LIVE	Digital Audio Gear	GK-2110	G-MIX 12X24	G-MIX-L 1224		
LINE 6	POD XT (SHARC POD)	Digital Audio Gear	G-MIX-B 1212	G-TOUR 12X17			
LINE 6	POD XT LIVE	Digital Audio Gear	GK-2110	G-MIX 12X24	G-MIX-L 1224	G-MIX-L 1622	G-MIX-L 1724
LINE 6	POD XT PRO	Digital Audio Gear	GK-2110	G-MIX 12X24	G-MIX-L 1224		
LINE 6	POD-Pro	Digital Audio Gear	GK-2110	G-MIX 12X24	G-MIX-L 1224		
LINE 6	SPIDER 212	Amp/Cabinet	G-212A	G-TOUR AMP2430			
LINE 6	SPIDER II 112	Amp/Cabinet	G-112A	G-TOUR AMP2226			
LINE 6	SPIDER II 210	Amp/Cabinet	G-112A	G-TOUR AMP2226			
LINE 6	SPIDER II 212	Amp/Cabinet	G-212-ROTO	G-901	G-TOUR AMP HEAD		
LINE 6	SPIDER II 412	Amp/Cabinet	G-TOUR-4X12-CAB				
LINE 6	SPIDER II HD	Amp/Cabinet	G-212-ROTO	G-901	G-TOUR AMP HEAD		
LINE 6	SPIDER II HD75	Amp/Cabinet	G-212-ROTO	G-901	G-TOUR AMP HEAD		
LINE 6	SPIDER III 120	Amp/Cabinet	G-112A	G-TOUR AMP2226			
LINE 6	SPIDER III 150	Amp/Cabinet	G-212A	G-TOUR AMP2430			
LINE 6	SPIDER III 75	Amp/Cabinet	G-112A	G-TOUR AMP2226			
LINE 6	SPIDER III HD150	Amp/Cabinet	G-212-ROTO	G-901	G-TOUR AMP HEAD		
LINE 6	SPIDER III HD75	Amp/Cabinet	G-212-ROTO	G-901	G-TOUR AMP HEAD		
LINE 6	TONEPORTR GX1	Digital Audio Gear	G-MIX-B 1212				
LINE 6	TONEPORTR KB37	Keyboard	GK-2110	GK-LT25W			
LINE 6	TONEPORTR UX1	Digital Audio Gear	G-MIX-B 1212				
LINE 6	VETTA HEAD	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
LINE 6	VETTA II CAB	Amp/Cabinet	G-TOUR-4X12-CAB				
LINE 6	VETTA II HEAD	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
MACKIE	1202 VLZ PRO	Mixer	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
MACKIE	1202-VLZ3	Mixer	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
MACKIE	1402 VLZ PRO	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618
MACKIE	1402-VLZ3	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618
MACKIE	1604 VLZ PRO	Mixer	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21	
MACKIE	1604-VLZ3	Mixer	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21	
MACKIE	1642 VLZ Pro	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21	
MACKIE	1642-VLZ3	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21	
MACKIE	402-VLZ3	Mixer	G-MIX-B 1212				
MACKIE	802-VLZ3	Mixer	G-MIX-B 1212	G-MIX-B 1515			
MACKIE	C200	Speaker	GPA-600				
MACKIE	C300Z	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
MACKIE	CFX 12	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618	G-TOUR 19X21	
MACKIE	CFX 16	Mixer	G-MIX 20X25	G-MIX-B 2519	G-MIX-L 1622	G-MIX-L 1822	G-TOUR 20X25
MACKIE	CFX 20	Mixer	G-MIX 20X30	G-TOUR 20X30			
MACKIE	CFX12mk2	Mixer	G-MIX 19X21	G-MIX-B 2020	G-MIX-L 1622	G-TOUR 19X21	
MACKIE	CFX16mk2	Mixer	G-MIX 20X25	G-MIX-B 2519	G-TOUR 20X25		
MACKIE	CFX20mk2	Mixer	G-MIX 20X30	G-TOUR 20X30			
MACKIE	D2	Mixer	G-MIX-B 1815	G-TOUR 12X17			
MACKIE	HRS120	Speaker	G-SUB2225-24BAG				
MACKIE	HUI	Mixer	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21	
MACKIE	LINK USB	Digital Audio Gear	G-MIX-B 1212				
MACKIE	MS1402-VLZ	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618
MACKIE	ONYX 1620	Mixer	G-MIX 19X21	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	
MACKIE	ONYX 1640	Mixer	G-MIX 20X25	G-MIX-B 2519	G-TOUR 20X25		
MACKIE	PPM1008	Mixer	GPA-720				
MACKIE	PPM1012	Mixer	G-MIX 19X21	G-MIX-B 2020	G-MIX-L 1822	G-TOUR 19X21	
MACKIE	PPM608	Mixer	GPA-720				
MACKIE	PRO FX12	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-L 1618		
MACKIE	PRO FX8	Mixer	G-MIX 20X25	G-MIX 20X30	G-MIX-B 2519	G-TOUR 20X25	
MACKIE	SATELLITE BASE	Digital Audio Gear	G-MIX-B 1212				
MACKIE	SRM350	Speaker	GPA-600				
MACKIE	SRM450	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
MACKIE	SRM450-V2	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
MACKIE	SWA1501	Speaker	G-SUB2225-24BAG				
MACKIE	TAPCO 6306	Mixer	G-MIX-B 1212				
MACKIE	U.420	Mixer	G-MIX-B 1212				
MACKIE	DFX 12	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 19X21	
MACKIE	DFX 6	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-L 1618	G-TOUR 12X17	
MACKIE	ONYX 1220	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 19X21	
MARANTZ	CDR310	Digital Audio Gear	G-MIX-B 1212				
MARANTZ	PD4293D	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
MARANTZ	PD5010D	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
MARANTZ	PMD671	Digital Audio Gear	G-MIX-B 1212				
MARSHALL	1912	Amp/Cabinet	G-112A				
MARSHALL	1922	Amp/Cabinet	G-212A	G-TOUR AMP2430			
MARSHALL	1936	Amp/Cabinet	G-TOUR AMP2430				
MARSHALL	2203	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
MARSHALL	2245	Amp/Cabinet	G-212-ROTO	G-901			
MARSHALL	2266	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
MARSHALL	2466	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
MARSHALL	4100	Amp/Cabinet	G-TOUR AMP HEAD				
MARSHALL	1959SLPX	Amp/Cabinet	G-212-ROTO	G-901			
MARSHALL	1962BLUESBREAKER	Amp/Cabinet	G-212A	G-TOUR AMP2430			
MARSHALL	1974CX	Amp/Cabinet	G-TOUR AMP2226				
MARSHALL	1982 AJH	Amp/Cabinet	G-TOUR-4X12-CAB				
MARSHALL	1987X	Amp/Cabinet	G-212-ROTO	G-901			
MARSHALL	2203K	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
MARSHALL	2266C	Amp/Cabinet	G-212A	G-TOUR AMP2430			
MARSHALL	425A	Amp/Cabinet	G-TOUR-4X12-CAB				
MARSHALL	425B	Amp/Cabinet	G-TOUR-4X12-CAB				
MARSHALL	AS100D	Amp/Cabinet	G-212-ROTO				

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
MARSHALL	AS50D	Amp/Cabinet	G-112A	G-TOUR AMP2226			
MARSHALL	AVT100X	Amp/Cabinet	G-TOUR AMP2226				
MARSHALL	AVT112X	Amp/Cabinet	G-TOUR AMP2226				
MARSHALL	AVT150	Amp/Cabinet	G-TOUR AMP2226				
MARSHALL	AVT150H	Amp/Cabinet	G-212-ROTO	G-901	G-TOUR AMP HEAD		
MARSHALL	AVT150HX	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
MARSHALL	AVT150X	Amp/Cabinet	G-TOUR AMP2226				
MARSHALL	AVT275X	Amp/Cabinet	G-212A	G-TOUR AMP2430			
MARSHALL	AVT412A	Amp/Cabinet	G-TOUR-4X12-CAB				
MARSHALL	AVT412B	Amp/Cabinet	G-TOUR-4X12-CAB				
MARSHALL	AVT412XA	Amp/Cabinet	G-TOUR-4X12-CAB				
MARSHALL	AVT412XB	Amp/Cabinet	G-TOUR-4X12-CAB				
MARSHALL	AVT50H	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
MARSHALL	AVT50HX	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
MARSHALL	AVT50X	Amp/Cabinet	G-TOUR AMP2226				
MARSHALL	AVT-50X	Amp/Cabinet	G-TOUR AMP2226				
MARSHALL	B65	Amp/Cabinet	G-TOUR AMP2226				
MARSHALL	DSL100	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
MARSHALL	DSL401	Amp/Cabinet	G-112A	G-TOUR AMP2226			
MARSHALL	DSL50	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
MARSHALL	JCM800	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
MARSHALL	JCM800 2203X	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
MARSHALL	JCM900	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
MARSHALL	JCM-900	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
MARSHALL	JTM100	Amp/Cabinet	G-212-ROTO	G-901			
MARSHALL	JTM45	Amp/Cabinet	G-212-ROTO	G-901			
MARSHALL	JVM410C	Amp/Cabinet	G-212A	G-TOUR AMP2430			
MARSHALL	JVM410H	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
MARSHALL	LEAD 100 MOSFET	Amp/Cabinet	G-212-ROTO	G-901			
MARSHALL	MB4210	Amp/Cabinet	G-212A	G-TOUR AMP2226	G-TOUR AMP2430		
MARSHALL	MB60	Amp/Cabinet	G-TOUR AMP2226				
MARSHALL	MF350	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
MARSHALL	MG100DFX	Amp/Cabinet	G-TOUR AMP2226				
MARSHALL	MG100HDFX	Amp/Cabinet	G-112-ROTO	G-212-ROTO			
MARSHALL	MG250 DFX	Amp/Cabinet	G-212A	G-TOUR AMP2226	G-TOUR AMP2430		
MARSHALL	MG250DFX	Amp/Cabinet	G-212A	G-TOUR AMP2430			
MARSHALL	MG412	Amp/Cabinet	G-TOUR-4X12-CAB				
MARSHALL	MG50DFX	Amp/Cabinet	G-TOUR AMP2226				
MARSHALL	SUPER100JH	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
MARSHALL	TSL100	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
MARSHALL	TSL122	Amp/Cabinet	G-212A	G-TOUR AMP2430			
MARSHALL	TSL60	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
MARSHALL	TSL601	Amp/Cabinet	G-112A	G-TOUR AMP2226			
MARSHALL	TSL602	Amp/Cabinet	G-212A	G-TOUR AMP2430			
MARSHALL	VBA400	Amp/Cabinet	G-212-ROTO	G-TOUR AMP HEAD			
MARSHALL	VM2266C	Amp/Cabinet	G-TOUR AMP2430				
MARSHALL	VM2266H	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
MARSHALL	VM2466H	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
M-AUDIO	2	Keyboard	GK-2110				
M-AUDIO	AXIOM 25 KEY	Keyboard	GK-2110				
M-AUDIO	AXIOM 49 KEY	Keyboard	GK-249	GKB-49			
M-AUDIO	AXIOM 61	Keyboard	GK-4212				
M-AUDIO	BLACK BOX	Digital Audio Gear	G-MIX-B 1212				
M-AUDIO	FIREWIRE 1814	Digital Audio Gear	G-MIX-B 1212				
M-AUDIO	FIREWIRE 410	Digital Audio Gear	G-MIX-B 1212				
M-AUDIO	FIREWIRE SOLO	Digital Audio Gear	G-MIX-B 1515	G-MIX-B 1815	G-TOUR 12X17		
M-AUDIO	KEYRIG 49	Keyboard	GK-249				
M-AUDIO	KEYSTATION 49E	Keyboard	GK-249				
M-AUDIO	KEYSTATION 61ES	Keyboard	GK-261R	GK-4212	G-TOUR 61		
M-AUDIO	KEYSTATION 88 ES	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
M-AUDIO	KEYSTUDIO 49i	Keyboard	GK-249				
M-AUDIO	O2 25 KEY	Keyboard	GK-2110				
M-AUDIO	OXYGEN 49	Keyboard	GK-249	GKB-49			
M-AUDIO	OXYGEN 61	Keyboard	GK-4212	GK-49			
M-AUDIO	PRO88	Keyboard	GK-288SLIM-XLNG	GK-88	GKB-88		
M-AUDIO	PROJECT MIN I/O	Amp/Cabinet	G-212A	G-TOUR AMP2226	G-TOUR AMP2430		
M-AUDIO	PROJECT MIX I/O	Digital Audio Gear	G-MIX 19X21	G-MIX-B 2118	G-TOUR 19X21		
M-AUDIO	PROKEYS 88SX	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
M-AUDIO	RADIUM61	Keyboard	GK-249				
M-AUDIO	SONO61	Keyboard	GK-4212				
M-AUDIO	TRIGGERFINGER	Digital Audio Gear	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
MAXENT	MX-42VM10	LCD/Plasma	G-LCD-4647				
MESABOOGIE	112 COMPACT OPEN BACK	Amp/Cabinet	G-112-ROTO				
MESABOOGIE	112 LONESTAR 23	Amp/Cabinet	G-112A	G-TOUR AMP2226			
MESABOOGIE	112 THREE-QUARTER BACK	Amp/Cabinet	G-212A	G-TOUR AMP2430			
MESABOOGIE	112 WIDE BODY	Amp/Cabinet	G-112A	G-TOUR AMP2226			
MESABOOGIE	410 LONESTAR	Amp/Cabinet	G-TOUR-4X12-CAB				
MESABOOGIE	412 LONESTAR	Amp/Cabinet	G-TOUR-4X12-CAB				
MESABOOGIE	412 STILETTO	Amp/Cabinet	G-TOUR-4X12-CAB				
MEYER SOUND	M1D SUB	Speaker	GPA-700	GPA-777			
MEYER SOUND	UMS-1P	Speaker	GPA-700				
MIBSUBISHI	LT-46149	LCD/Plasma	G-LCD-4647				
MICROBOARDS	COPYWRITER 1052	Digital Audio Gear	G-MIX 20X25	G-MIX-B 2519	G-TOUR 20X25		
MICROBOARDS	DVD RPM 1016	Digital Audio Gear	G-MIX 20X25	G-MIX-B 2519	G-TOUR 20X25		
MICROTEK	MHP1	LCD/Plasma	G-TOURLCDP50				

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
MICROTEK	VS1	Projector	GAV-1412-R	GAV-1813-UR	GAV-DLX-1412R	GAV-PE-1412R	
MIDAS	VENICE-1608	Mixer	G-MIX 20X25	G-TOUR 20X25			
MISUBISHI	XD450U	Projector	GAV-1412-R	GAV-1813-UR	GAV-DLX-1412R	GAV-PE-1412R	
mitsubishi	LEONARDO	LCD/Plasma	G-LCD-4042				
MITSUBISHI	LT46231	LCD/Plasma	G-TOURLCDP50				
MITSUBISHI	LT-52133	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
MITSUBISHI	LT-52144	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
MITSUBISHI	LT-52244	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
MITSUBISHI	PD-5010	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
MITSUBISHI	XD430U	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
MITSUBISHI	XL8U	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
MOTU	TRAVELER	Digital Audio Gear	G-MIX-B 1515	G-TOUR 12X17			
MOTU	ULTRALITE	Digital Audio Gear	G-MIX-B 1212				
MUSICXPC	M4	Laptop	GAV-1813-UR	G-TOURCARRYON			
MUSICXPC	M4X	Laptop	GAV-1813-UR	G-TOURCARRYON			
MusicXPC	M6	Laptop	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYON
NADY	6600	Mixer	GPA-720				
NADY	CMX16A	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 19X21	
NADY	DKW-DUO	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
Nady	E03	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
Nady	Encore Duet Dual Headset	Wireless System	GM-1W	GM-1WP	GM-2W		
Nady	Encore Duet Dual Lavalier	Wireless System	GM-1W	GM-1WP	GM-2W		
NADY	MC12	Speaker	GPA-450-515	GPA-600	GPA-700	GPA-777	GPA-SCVR450-515
NADY	MC15	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
NADY	MM 4	Mixer	G-MIX-B 1212				
NADY	MPM8175	Mixer	GPA-720				
NADY	MXE1212	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618	G-TOUR 19X21	
NADY	MXE612	Mixer	G-MIX-B 1212				
NADY	MXE812	Mixer	G-MIX-B 1212				
NADY	PFW12	Speaker	GPA-700	G-SUB2225-24BAG			
NADY	PRM400	Mixer	G-MIX 17X18	G-MIX-B 2118	G-MIX-L 1618	G-TOUR 19X21	
NADY	PS112	Speaker	GPA-450-515	GPA-600	GPA-700	GPA-777	GPA-SCVR450-515
NADY	PSW15	Speaker	GPA-700	G-SUB2225-24BAG			
NADY	PTS 1015	Speaker	GPA-700	GPA-777			
NADY	PTS515	Speaker	GPA-700	GPA-777			
NADY	SPM6600	Mixer	GPA-720				
NADY	SPM8600	Mixer	GPA-720				
NADY	SRM10X	Mixer	G-MIX-B 1212				
NADY	SRM12X	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17
NADY	SRM-14X	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618
Nady	UHF-3	Wireless System	GM-1W	GM-1WP	GM-2W		
NEC	3300	LCD/Plasma	G-TOURLCDP-2632				
NEC	4000	LCD/Plasma	G-TOURLCD-3743T				
NEC	4200	LCD/Plasma	G-LCD-4042	G-LCD-4647			
NEC	4205	LCD/Plasma	G-LCD-4042	G-LCD-4647			
NEC	4210	LCD/Plasma	G-LCD-4042	G-LCD-4647			
NEC	5000	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
NEC	42MP1	LCD/Plasma	G-LCD-4042	G-LCD-4647			
NEC	42MP2	LCD/Plasma	G-LCD-4042	G-LCD-4647			
NEC	42MP4	LCD/Plasma	G-LCD-4042	G-LCD-4647			
NEC	42PD1	LCD/Plasma	G-TOURLCD-3743T				
NEC	42PD2	LCD/Plasma	G-TOURLCD-3743T				
NEC	42VM5	LCD/Plasma	G-TOURLCD-3743T				
NEC	42VP4	LCD/Plasma	G-TOURLCD-3743T				
NEC	42VP5 & 42VP5A	LCD/Plasma	G-TOURLCD-3743T				
NEC	42XM3	LCD/Plasma	G-TOURLCD-3743T				
NEC	42XM3A	LCD/Plasma	G-TOURLCD-3743T				
NEC	50MP1	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
NEC	50MP2	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
NEC	50MP3	LCD/Plasma	G-TOURLCDP50				
NEC	50PD1	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
NEC	50XM3	LCD/Plasma	G-TOURLCDP50				
NEC	50XM4A	LCD/Plasma	G-TOURLCDP50				
NEC	50XM5	LCD/Plasma	G-TOURLCDP50				
NEC	50XR4A	LCD/Plasma	G-TOURLCDP50				
NEC	61 XMA	LCD/Plasma	G-TOURLCDP60				
NEC	61 XR4	LCD/Plasma	G-TOURLCDP60				
NEC	LCD2170NX	LCD/Plasma	G-TOURLCDP-2023				
NEC	LCD2180WGLED	LCD/Plasma	G-TOURLCDP-2023				
NEC	LCD2335 WXM	LCD/Plasma	G-TOURLCDP-2023				
NEC	LCD4010	LCD/Plasma	G-TOURLCD-3743T				
NEC	LCD4215	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
NEC	LCD4610	LCD/Plasma	G-LCD-4647				
NEC	LCD4615	LCD/Plasma	G-LCD-4647				
NEC	LCD4620	LCD/Plasma	G-TOURLCD-3743T				
NEC	LCD46202AV	LCD/Plasma	G-TOURLCD-3743T				
NEC	LCD5220	LCD/Plasma	G-TOURLCDP50				
NEC	LCD5710-2-AV	LCD/Plasma	G-TOURLCDP60				
NEC	LCD5710-2-IT	LCD/Plasma	G-TOURLCDP60				
NEC	LCD6520L-BK	LCD/Plasma	G-TOURLCDLIFT65				
NEC	LT150Z	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYON
NEC	M40B-AV	LCD/Plasma	G-TOURLCD-3743T				
NEC	P42XC10	LCD/Plasma	G-LCD-4042	G-LCD-4647			
NEC	P42XP10-BK	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
NEC	P50XC10	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
NEC	P50XP10	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
NEC	P60XC10	LCD/Plasma	G-TOURLCDP60				
NEC	P60XP10-BK	LCD/Plasma	G-TOURLCDP60				
NEC	PX-42V5RA	LCD/Plasma	G-TOURLCD-3743T				
NEC	PX-42VMA	LCD/Plasma	G-TOURLCD-3743T				
NEC	PX-42VP4A	LCD/Plasma	G-TOURLCD-3743T				
NEC	PX-42XM2A	LCD/Plasma	G-TOURLCD-3743T				
NEC	VT-37	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R		
NEC	VT-47	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R		
NEC	VT-470	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R		
NEC	VT-570	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R		
NEC	VT-575	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R		
NEC	VT-670	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R		
NEC	VT-676	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R		
NEC	VT-770	Projector	G-TOURCARRYON				
NEC	X461UN	LCD/Plasma	G-TOURLCD-3743T				
NORD	ELECTRO 2 61	Keyboard	GK-249	GK-49	GKB-49		
NORD	ELECTRO 2 73	Keyboard	GK-261R	G-TOUR 61			
NORD	NC1	Keyboard	GK-61	GKB-61	GKC-1540		
NORD	STAGE 88	Keyboard	GK-276R	GK-76	GKB-76	G-TOUR 76	
NOVATION	REMOTE ZERO SL	Digital Audio Gear	GK-2110	G-MIX 12X24	G-MIX-L 1224		
NOVATION	REMOTE25 SL	Keyboard	GK-2110				
NOVATION	REMOTE25 SLC	Keyboard	GK-2110				
NOVATION	REMOTE-25LE	Keyboard	GK-2110				
NOVATION	REMOTE37 SL	Keyboard	GK-2110				
NOVATION	REMOTE49	Keyboard	GK-249	GKB-49			
NOVATION	REMOTE49 SLC	Keyboard	GK-249	GKB-49			
NOVATION	REMOTE-49LE	Keyboard	GK-249				
NOVATION	REMOTE61	Keyboard	GK-4212				
NOVATION	REMOTE-61LE	Keyboard	GK-4212				
NOVATION	XIO-SYNTH25	Keyboard	GK-2110				
NOVATION	XIO-SYNTH49	Keyboard	GK-249				
NOVATION	XSTATION 25	Keyboard	GK-2110				
NOVATION	XSTATION 49	Keyboard	GK-249	GKB-49			
NOVATION	XSTATION 61	Keyboard	GK-4212				
NUMARK	5000FX	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618
NUMARK	AXIS 2	CD/DVD Player	G-TOUR CD-13X17				
NUMARK	AXIS 4	CD/DVD Player	G-TOUR CD-13X17				
NUMARK	AXIS 8	CD/DVD Player	G-TOUR CD-9X12				
NUMARK	AXIS 9	CD/DVD Player	G-TOUR CD-9X12				
NUMARK	CD2CD	CD/DVD Player	G-TOUR CD-13X17	G-TOUR CD-9X12			
NUMARK	DM1001X	Mixer	G-MIX-B 1212	G-MIX-B 1515			
NUMARK	DM1002 MKII	Mixer	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
NUMARK	DM1050	Mixer	G-MIX-B 1212	G-MIX-B 1515			
NUMARK	DM2050	Mixer	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
NUMARK	DM3001X	Mixer	G-MIX-B 1515	G-TOUR 12X17			
NUMARK	DM3002X	Mixer	G-MIX-B 1515	G-TOUR 12X17			
NUMARK	DM3050	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-TOUR 12X17		
NUMARK	DM950	Mixer	G-MIX-B 1212				
NUMARK	DM950 USB	Mixer	G-MIX-B 1212				
NUMARK	DMX01	Mixer	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
NUMARK	DMX03	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-TOUR 12X17		
NUMARK	DMX06	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-TOUR 12X17		
NUMARK	DXM01 USB	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-TOUR 12X17		
NUMARK	DXM06	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-TOUR 12X17		
NUMARK	DXM09	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-TOUR 12X17		
NUMARK	DXMPRO	Mixer	G-MIX-B 2118	G-MIX-L 1822			
NUMARK	HDX	Turntable	GDJ-1500	GDJ-2500	G-TOUR T-TABLE		
NUMARK	iCDX	CD/DVD Player	G-TOUR CD-13X17				
NUMARK	iDJ	Mixer	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
NUMARK	IDJ2	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-B 1818	G-MIX-B 2118	G-MIX-L 1618
NUMARK	M3	Mixer	G-MIX-B 1212				
NUMARK	MATRIX 2	Mixer	G-TOUR 12X17				
NUMARK	MATRIX 3	Mixer	G-TOUR 12X17				
NUMARK	MIX MEISTER CONTROL	Mixer	G-MIX 12X24	G-MIX-L 1224	G-MIX-L 1622	G-MIX-L 1724	
NUMARK	NUVJ	Mixer	G-MIX 20X25	G-MIX-B 2519	G-TOUR 20X25		
NUMARK	PPD01	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-TOUR 12X17		
NUMARK	TT1600MKII	Turntable	GDJ-1500	G-TOUR T-TABLE			
NUMARK	TT1650	Turntable	GDJ-1500	GDJ-2500	G-TOUR T-TABLE		
NUMARK	TT200	Turntable	GDJ-1500				
NUMARK	TT500	Turntable	GDJ-1500	G-TOUR T-TABLE			
NUMARK	TTUSB	Turntable	GDJ-1500	GDJ-2500	G-TOUR T-TABLE		
NUMARK	TTX	Turntable	GDJ-1500	G-TOUR T-TABLE			
NUMARK	VJ01	CD/DVD Player	G-TOUR CD-13X17				
OLYMPUS	VP1	Projector	G-TOURCARRYON				
OPEN LABS	NEKO 64 61	Keyboard	GK-276-DEEP				
OPEN LABS	NEKO LE 61	Keyboard	GK-276-DEEP				
OPTOMA	EZ PRO 716	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONP	
OPTOMA	EZ PRO 719	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONP	
OPTOMA	EZ PRO 729	Projector	G-TOURCARRYON				
OPTOMA	EZ PRO 732	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONP
OPTOMA	EZ PRO 747	Projector	GAV-1412-R	GAV-1813-UR	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONP
PANASONIC	46PZ80U	LCD/Plasma	G-TOURLCDP50				
PANASONIC	46PZ85U	LCD/Plasma	G-TOURLCDP50				
PANASONIC	PT-37PD1	LCD/Plasma	G-TOURLCD-3743T				

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
PANASONIC	PT-42P1	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
PANASONIC	PT-50PD3-P	LCD/Plasma	G-TOURLCDP50				
PANASONIC	PT-AE700U	Projector	GAV-1412-R	GAV-1813-UR	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONF
PANASONIC	PT-L500U	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
PANASONIC	PTLB10SVU	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
PANASONIC	PT-LB10U	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
PANASONIC	PTLB10VU	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
PANASONIC	PT-LB20NTU	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
PANASONIC	PTLB20SU	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
PANASONIC	PTLB20U	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
PANASONIC	PTLB20VU	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
PANASONIC	PT-LB30	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
PANASONIC	PTLB30NTU	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
PANASONIC	PTLB50NTU	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
PANASONIC	PTLB50SU	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
PANASONIC	PTLB50U	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
PANASONIC	PTLB60NTU	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
PANASONIC	PTLB60U	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
PANASONIC	PT-LM1	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONF
PANASONIC	PT-LM2	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONF
PANASONIC	TC23LX50	LCD/Plasma	G-TOURLCDP-2023				
PANASONIC	TC-32LX60	LCD/Plasma	G-TOURLCDP-2632				
PANASONIC	TC-37P1F	LCD/Plasma	G-TOURLCD-3743T				
PANASONIC	TC-L32C12	LCD/Plasma	G-TOURLCDP-2632				
PANASONIC	TC-L42U12	LCD/Plasma	G-LCD-4042	G-LCD-4647			
PANASONIC	TC-P42C1	LCD/Plasma	G-LCD-4042	G-LCD-4647			
PANASONIC	TCP42S1	LCD/Plasma	G-LCD-4042	G-LCD-4647			
PANASONIC	TC-P42U1	LCD/Plasma	G-LCD-4042	G-LCD-4647			
PANASONIC	TC-P42X1	LCD/Plasma	G-LCD-4042	G-LCD-4647			
PANASONIC	TCP46G10	LCD/Plasma	G-LCD-4647	G-TOURLCDP50			
PANASONIC	TCP46S1	LCD/Plasma	G-LCD-4647	G-TOURLCDP50			
PANASONIC	TCP46U1	LCD/Plasma	G-LCD-4647	G-TOURLCDP50			
PANASONIC	TC-P50G10	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
PANASONIC	TC-P50S1	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
PANASONIC	TC-P50U1	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
PANASONIC	TC-P50X1	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
PANASONIC	TC-P54S1	LCD/Plasma	G-TOURLCDLIFT52				
PANASONIC	TH-37PR11UK/UH	LCD/Plasma	G-LCD-4042				
PANASONIC	TH-42PD60U	LCD/Plasma	G-LCD-4647				
PANASONIC	TH-42PDD3B	LCD/Plasma	G-TOURLCD-3743T				
PANASONIC	TH-42PF11UK	LCD/Plasma	G-TOURLCD-3743T				
PANASONIC	TH-42PH11UK	LCD/Plasma	G-TOURLCD-3743T				
PANASONIC	TH-42PH9UK	LCD/Plasma	G-TOURLCD-3743T				
PANASONIC	TH-42PHD5UY	LCD/Plasma	G-TOURLCD-3743T				
PANASONIC	TH-42PHD6	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
PANASONIC	TH-42PHD6UY	LCD/Plasma	G-TOURLCD-3743T				
PANASONIC	TH-42PHD7UY	LCD/Plasma	G-TOURLCD-3743T				
PANASONIC	TH-42PHD8UK	LCD/Plasma	G-TOURLCD-3743T				
PANASONIC	TH-42PR11UK/UH	LCD/Plasma	G-LCD-4042	G-LCD-4647			
PANASONIC	TH42PS9UK	LCD/Plasma	G-TOURLCD-3743T				
PANASONIC	TH-42PWD3U	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
PANASONIC	TH-42PWD5UY	LCD/Plasma	G-TOURLCD-3743T				
PANASONIC	TH-42PWD6UY	LCD/Plasma	G-TOURLCD-3743T				
PANASONIC	TH42PX25U	LCD/Plasma	G-LCD-4647	G-TOURLCDP50			
PANASONIC	TH-42PX600U	LCD/Plasma	G-LCD-4647				
PANASONIC	TH-42PX60U	LCD/Plasma	G-LCD-4042	G-LCD-4647			
PANASONIC	TH46PZ80U	LCD/Plasma	G-TOURLCDP50				
PANASONIC	TH46PZ85U	LCD/Plasma	G-TOURLCDP50				
PANASONIC	TH-50PF11UK	LCD/Plasma	G-TOURLCDP50				
PANASONIC	TH50PF9UK	LCD/Plasma	G-TOURLCDP50				
PANASONIC	TH-50PH11UK	LCD/Plasma	G-TOURLCDP50				
PANASONIC	TH-50PH9	LCD/Plasma	G-TOURLCDP50				
PANASONIC	TH-50PH9UK	LCD/Plasma	G-TOURLCDP50				
PANASONIC	TH-50PHD3U	LCD/Plasma	G-TOURLCDP50				
PANASONIC	TH-50PHD5UY	LCD/Plasma	G-TOURLCDP50				
PANASONIC	TH-50PHD7UY	LCD/Plasma	G-TOURLCDP50				
PANASONIC	TH-50PX	LCD/Plasma	G-TOURLCDP50				
PANASONIC	TH-50PX6	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
PANASONIC	TH-50THD6UI	LCD/Plasma	G-TOURLCDP50				
PANASONIC	TH-50THD6UY	LCD/Plasma	G-TOURLCDP50				
PANASONIC	TH-58PF11UK	LCD/Plasma	G-TOURLCDP60				
PANASONIC	TH-58PH10UKA	LCD/Plasma	G-TOURLCDP60				
PANASONIC	TH58PX6	LCD/Plasma	G-TOURLCDP60				
PANASONIC	TH-58PZ800U	LCD/Plasma	G-TOURLCDP60				
PEAVEY	24FX	Mixer	G-MIX 20X25	G-MIX-B 2519	G-TOUR 20X25		
PEAVEY	5150 HEAD	Amp/Cabinet	G-212-ROTO	G-901	G-TOUR AMP HEAD		
PEAVEY	6505 HEAD	Amp/Cabinet	G-212-ROTO	G-901	G-TOUR AMP HEAD		
PEAVEY	6505 PLUS HEAD	Amp/Cabinet	G-212-ROTO	G-901	G-TOUR AMP HEAD		
PEAVEY	BANDIT 112	Amp/Cabinet	G-TOUR AMP2226				
PEAVEY	CLASSIC 212	Amp/Cabinet	G-TOUR-4X12-CAE				
PEAVEY	CLASSIC 30	Amp/Cabinet	G-112A				
PEAVEY	CLASSIC 30 HEAD	Amp/Cabinet	G-112-ROTO				
PEAVEY	CLASSIC 50/212	Amp/Cabinet	G-212A	G-TOUR AMP2430			
PEAVEY	CLASSIC 50/410	Amp/Cabinet	G-212A	G-TOUR AMP2430			
PEAVEY	DELTA BLUES 115	Amp/Cabinet	G-TOUR AMP2226				

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
PEAVEY	DELTA BLUES 210	Amp/Cabinet	G-TOUR AMP2226				
PEAVEY	JSX 212COMBO	Amp/Cabinet	G-212A	G-TOUR AMP2430			
PEAVEY	JSX HEAD	Amp/Cabinet	G-212-ROTO	G-TOUR AMP HEAD			
PEAVEY	JSX412	Amp/Cabinet	G-TOUR-4X12-CAB				
PEAVEY	MAX 115	Amp/Cabinet	G-TOUR AMP2226	G-TOUR AMP2430			
PEAVEY	MP600	Mixer	GPA-720				
PEAVEY	NASHVILLE 1000	Amp/Cabinet	G-212A	G-TOUR AMP2430			
PEAVEY	NASHVILLE 112	Amp/Cabinet	G-112A	G-TOUR AMP2226			
PEAVEY	PENTA 412	Amp/Cabinet	G-TOUR-4X12-CAB				
PEAVEY	PENTA HEAD	Amp/Cabinet	G-TOUR AMP HEAD				
PEAVEY	PR 10 NEO	Speaker	GPA-600				
PEAVEY	PR 12 NEO	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
PEAVEY	PR12	Speaker	GPA-700				
PEAVEY	PV 12M	Speaker	GPA-700				
PEAVEY	PV 15M	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
PEAVEY	PV10	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618
PEAVEY	PV14	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 19X21	
PEAVEY	PV20	Mixer	G-MIX 20X25	G-MIX-B 2519	G-MIX-L 1622	G-TOUR 20X25	
PEAVEY	PV6	Mixer	G-MIX-B 1212				
PEAVEY	PV8	Mixer	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
PEAVEY	RQ 1606M	Mixer	G-MIX 20X30	G-TOUR 20X30			
PEAVEY	RQ 200	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-TOUR 12X17		
PEAVEY	RQ 2310	Mixer	G-MIX 19X21	G-MIX-B 2020	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21
PEAVEY	RQ 2314	Mixer	G-MIX 19X21	G-MIX 20X25	G-MIX-B 2519	G-TOUR 19X21	G-TOUR 20X25
PEAVEY	RQ 2318	Mixer	G-MIX 20X25	G-MIX 20X30	G-MIX-B 2519	G-TOUR 20X25	G-TOUR 20X30
PEAVEY	STUDIO PRO 112	Amp/Cabinet	G-112A	G-TOUR AMP2226			
PEAVEY	SUPREME XL HEAD	Amp/Cabinet	G-212-ROTO	G-TOUR AMP HEAD			
PEAVEY	TRANSTUBE 110 EFX	Amp/Cabinet	G-112-ROTO				
PEAVEY	TRANSTUBE 112 EFX	Amp/Cabinet	G-112A	G-TOUR AMP2226			
PEAVEY	TRIPLE XXX	Amp/Cabinet	G-212A	G-TOUR AMP2430			
PEAVEY	TRIPLE XXX 112	Amp/Cabinet	G-112A	G-TOUR AMP2226			
PEAVEY	TRIPLE XXX 212	Amp/Cabinet	G-212A	G-TOUR AMP2430			
PEAVEY	TRIPLE XXX 412	Amp/Cabinet	G-TOUR-4X12-CAB				
PEAVEY	TRIPLE XXX HEAD	Amp/Cabinet	G-212-ROTO	G-TOUR AMP HEAD			
PEAVEY	UNITY 1002-8 RQ	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21	
PEAVEY	VALVE KING 412	Amp/Cabinet	G-TOUR-4X12-CAB				
PEAVEY	VALVEKING 100 HEAD	Amp/Cabinet	G-212-ROTO	G-901	G-TOUR AMP HEAD		
PEAVEY	VALVEKING 112	Amp/Cabinet	G-112A	G-TOUR AMP2226			
PEAVEY	VALVEKING 212	Amp/Cabinet	G-212A	G-TOUR AMP2430			
PEAVEY	WIGGY 212	Amp/Cabinet	G-TOUR-4X12-CAB				
PEAVEY	WINDSOR 412	Amp/Cabinet	G-TOUR-4X12-CAB				
PEAVEY	WINDSOR HD	Amp/Cabinet	G-TOUR AMP HEAD				
PEAVEY	X XL	Amp/Cabinet	G-212A	G-TOUR AMP2430			
PEAVEY	XR 560	Mixer	GPA-720				
PEAVEY	XR 684F	Mixer	GPA-720				
PEAVEY	XR 800F PLUS	Mixer	G-MIX 19X21	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	
PEAVEY	XR600G	Mixer	GPA-720				
PEAVEY	XR696F	Mixer	GPA-720				
PEAVEY	XXL	Amp/Cabinet	G-212A	G-TOUR AMP2430			
PEAVEY	XXL HEAD	Amp/Cabinet	G-212-ROTO	G-TOUR AMP HEAD			
PHILIPS	20PF5120	LCD/Plasma	G-TOURLCDLP-2023				
PHILIPS	37PF9631D	LCD/Plasma	G-LCD-4042				
PHILIPS	42FD9932	LCD/Plasma	G-LCD-4647				
PHILIPS	42FD9934	LCD/Plasma	G-LCD-4647				
PHILIPS	42FD9935	LCD/Plasma	G-LCD-4647				
PHILIPS	42FD9955	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
PHILIPS	42PW9962	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
PHILIPS	42PW9982	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
PHILIPS	47PFL3603D/27	LCD/Plasma	G-LCD-4647	G-TOURLCDP50			
PHILIPS	47PFL7403D/27	LCD/Plasma	G-TOURLCDP50				
PHILIPS	50FD9955	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
PHILIPS	50PF7321	LCD/Plasma	G-TOURLCDP60				
PHILIPS	50PF9630A	LCD/Plasma	G-TOURLCDP60				
PHILIPS	50PF9830	LCD/Plasma	G-TOURLCDP60				
PHILIPS	52PFL7422D/37	LCD/Plasma	G-TOURLCDLIFT52				
PHILIPS	52PFL7432D/37	LCD/Plasma	G-TOURLCDLIFT52				
PHONIC	HELIX 18FW	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 19X21	
PHONIC	HELIX BOARD 12	Mixer	G-MIX-B 1212	G-MIX-B 1515			
PHONIC	HELIX BOARD 17	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-L 1618	G-TOUR 12X17	
PHONIC	MM1002	Mixer	G-MIX-B 1212				
PHONIC	MM1202	Mixer	G-MIX-B 1212	G-MIX-B 1515			
PHONIC	MM1705	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618
PHONIC	MM1805(X)	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618	G-TOUR 19X21	
PHONIC	MR 1843X	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618	G-TOUR 19X21	
PHONIC	MR3243	Mixer	G-MIX 24X36	G-TOUR 24X36			
PHONIC	MR4243(D)	Mixer	G-MIX 22X46				
PHONIC	MR4283	Mixer	G-MIX 22X46				
PHONIC	MR4283D	Mixer	G-MIX 22X46				
PHONIC	MRS 1-20	Mixer	G-MIX 24X36	G-TOUR 24X36			
PHONIC	MRS 1-30	Mixer	G-MIX 22X46				
PHONIC	MU1002	Mixer	G-MIX-B 1212				
PHONIC	MU1202	Mixer	G-MIX-B 1212	G-MIX-B 1515			
PHONIC	MU502	Mixer	G-MIX-B 1212				
PHONIC	MU802	Mixer	G-MIX-B 1212				
PHONIC	POWERPOD 1840	Mixer	G-MIX 19X21	G-MIX-B 2020	G-MIX-B 2118	G-TOUR 19X21	

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
PHONIC	POWERPOD 1860II	Mixer	G-MIX 19X21	G-MIX-B 2020	G-MIX-B 2118	G-TOUR 19X21	
PHONIC	POWERPOD 2280	Mixer	G-MIX 20X25	G-MIX-B 2519	G-TOUR 20X25		
PHONIC	POWERPOD 620	Mixer	GPA-720				
PHONIC	POWERPOD 740	Mixer	GPA-720				
PHONIC	POWERPOD 780+	Mixer	GPA-720				
PIONEER	614MX	LCD/Plasma	G-TOURLCDP60				
PIONEER	CDJ-1000 MK3	CD/DVD Player	G-TOUR CD-13X17				
PIONEER	CDJ-1000 MKII	CD/DVD Player	G-TOUR CD-13X17				
PIONEER	CDJ-100S	CD/DVD Player	G-TOUR CD-13X17	G-TOUR CD-9X12			
PIONEER	CDJ-200	CD/DVD Player	G-TOUR CD-13X17	G-TOUR CD-9X12			
PIONEER	CDJ-400	CD/DVD Player	G-TOUR CD-13X17	G-TOUR CD-9X12			
PIONEER	DJC3000RV	Turntable	GDJ-1500	GDJ-2500	G-TOUR T-TABLE		
PIONEER	DJM-300	Mixer	G-MIX-B 1515	G-TOUR 12X17			
PIONEER	DJM-3000	Mixer	G-MIX-L 1224				
PIONEER	DJM-300S	Mixer	G-MIX-B 1515	G-TOUR 12X17			
PIONEER	DJM-400	Mixer	G-MIX-B 1212	G-TOUR 12X17			
PIONEER	DJM-500	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618
PIONEER	DJM-600	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618
PIONEER	DJM-707	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-TOUR 12X17		
PIONEER	DJM-800	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618
PIONEER	DJM-909	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-TOUR 12X17		
PIONEER	DMP-555	CD/DVD Player	G-TOUR CD-13X17				
PIONEER	DVD-V7300D	Mixer	G-TOUR 12X17				
PIONEER	DVJ-1000	Turntable	GDJ-1500	GDJ-2500	G-TOUR T-TABLE		
PIONEER	EFX1000	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-TOUR 12X17		
PIONEER	EFX500	Mixer	G-MIX-B 1212	G-MIX-B 1515			
PIONEER	PDP 505CMX	LCD/Plasma	G-TOURLCDP50				
PIONEER	PDP 5070HD	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
PIONEER	PDP 6070	LCD/Plasma	G-TOURLCDP60				
PIONEER	PDP 6100	LCD/Plasma	G-TOURLCDP60				
PIONEER	PDP-401	LCD/Plasma	G-LCD-4042				
PIONEER	PDP-402	LCD/Plasma	G-LCD-4042				
PIONEER	PDP-4050HD	LCD/Plasma	G-TOURLCDP50				
PIONEER	PDP-4304	LCD/Plasma	G-LCD-4647	G-TOURLCD-3743T			
PIONEER	PDP-4330HD	LCD/Plasma	G-LCD-4647	G-TOURLCD-3743T			
PIONEER	PDP-433CMX	LCD/Plasma	G-LCD-4647	G-TOURLCD-3743T			
PIONEER	PDP-4340HD	LCD/Plasma	G-LCD-4647				
PIONEER	PDP-501	LCD/Plasma	G-TOURLCDP50				
PIONEER	PDP-502	LCD/Plasma	G-TOURLCDP50				
PIONEER	PDP-5020FD	LCD/Plasma	G-TOURLCDP50				
PIONEER	PDP-502MX	LCD/Plasma	G-TOURLCDP50				
PIONEER	PDP-5030HD	LCD/Plasma	G-TOURLCDP50				
PIONEER	PDP-503CMX	LCD/Plasma	G-TOURLCDP50				
PIONEER	PDP-5040HD	LCD/Plasma	G-TOURLCDP50				
PIONEER	PDP-505HD	LCD/Plasma	G-TOURLCDP50				
PIONEER	PDP-50MXE	LCD/Plasma	G-TOURLCDP50				
PIONEER	PDP-910HD	LCD/Plasma	G-LCD-4647				
PIONEER	PRO-1110HD	LCD/Plasma	G-TOURLCDP50				
PIONEER	SVM1000	Mixer	G-MIX 20X25	G-MIX-B 2519	G-TOUR 20X25		
PLANAR	PDP42B	LCD/Plasma	G-LCD-4042	G-LCD-4647			
PLANAR	PDP42HD	LCD/Plasma	G-LCD-4647				
PLASMASYNC	4210W	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
PLUS	U2-1200	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
PLUS	U4136	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONF
PLUS	U4232	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONF
PLUS	U5-111	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONF
PLUS	U5-112	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONF
PLUS	U5132	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONF
PLUS	U5-232	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONF
PLUS	U5-332	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONF
PLUS	V3-111	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONF
PLUS	V3-131	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONF
PLUS	V-332	Projector	G-TOURCARRYONF				
PLUS	XU4-136	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONF
POLYCOM	SOUNDSTATION2	Digital Audio Gear	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618
POLYCOM	VSX 3000	LCD/Plasma	G-TOURLCDP-202				
PRESONUS	STUDIOLIVE 16.4.2	Mixer	G-MIX 20X25	G-MIX-B 2519	G-TOUR 20X25		
PROSCAN	40LC45S	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T			
PYLE PRO	PYD-710	Mixer	G-MIX-B 1212				
PYLE-PRO	PYD1010	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17	
PYLE-PRO	PYD1015	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17	
PYLE-PRO	PYD1020	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17	
PYLE-PRO	PYD1910	Mixer	G-MIX 12X24	G-MIX-L 1224			
PYLE-PRO	PYD1920	Mixer	G-MIX 12X24	G-MIX-L 1224			
PYLE-PRO	PYD720	Mixer	G-MIX-B 1212				
QSC	K10	Speaker	GPA-600				
QSC	K12	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-E15	GPA-SCVR450-515
RANDALL	R412CB	Amp/Cabinet	G-TOUR-4X12-CAB				
RANDALL	R412CX	Amp/Cabinet	G-TOUR-4X12-CAB				
RANDALL	RA412XLT	Amp/Cabinet	G-TOUR-4X12-CAB				
RANDALL	RH150DG3	Amp/Cabinet	G-212-ROTO	G-901			
RANDALL	RM100M1	Amp/Cabinet	G-TOUR AMP HEAD				
RANDALL	RM100M2	Amp/Cabinet	G-TOUR AMP HEAD				
RANDALL	RM50HB	Amp/Cabinet	G-212-ROTO				
RANDALL	RM50HB2	Amp/Cabinet	G-212-ROTO				

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
RANDALL	TITAN 412	Amp/Cabinet	G-TOUR-4X12-CAB				
RANE	GRANDMASTER FLASH	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-TOUR 12X17		
RANE	TTM56	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-TOUR 12X17		
RANE	TTM57SL	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-TOUR 12X17		
RCA	L46FHD37	LCD/Plasma	G-LCD-4647	G-TOURLCDP50			
RCA	PH50300	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
RCA	PH50400	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
RCA	PH50500	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
RCA	PR42300	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
RCF	ART 310A	Speaker	GPA-450-515	GPA-600	GPA-E15	GPA-SCVR450-515	
RCF	ART 312A	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
RCF	ART 322A	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
RCF	ART 522-A	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
RCF	ART 525-A	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
RCF	ART 705-AS	Speaker	G-SUB2225-24BAG				
RCF	CW3110	Speaker	GPA-600				
RCF	CW5212	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
RCF	CW5215	Speaker	GPA-700				
RCF	SW4012	Speaker	GPA-600				
RENKUS-HEINZ	CF121M	Speaker	GPA-700				
REVOX	E-642	LCD/Plasma	G-TOURLCD-3743T				
REVOX	E-650	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
RMS RMS	10-400S	Mixer	GPA-720				
RMS RMS	6150R 6150R	Mixer	GPA-720				
ROCKTRON	UTOPIA G100	Digital Audio Gear	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618	G-MIX-L 1622	G-MIX-L 1822
ROCKTRON	UTOPIA G200	Digital Audio Gear	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618	G-MIX-L 1622	G-MIX-L 1822
ROLAND	AX-7	Keyboard	GK-4212				
ROLAND	CD2	Digital Audio Gear	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
ROLAND	CD2E	Digital Audio Gear	G-MIX-B 1212				
ROLAND	DJ-2000	Digital Audio Gear	G-MIX-L 1622	G-MIX-L 1822			
ROLAND	DR3	Digital Audio Gear	G-MIX-B 1212				
ROLAND	DR670	Digital Audio Gear	G-MIX-B 1212				
ROLAND	DR880	Digital Audio Gear	G-MIX-B 1212	G-MIX-B 1515			
ROLAND	E09	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
ROLAND	E80	Keyboard	GK-276-DEEP				
ROLAND	EXR-3	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
ROLAND	EXR46-OR	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
ROLAND	EXR-5	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
ROLAND	EXR-7	Keyboard	GK-276R	GK-76	GKB-76	G-TOUR 76	
ROLAND	FANTOM G6	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
ROLAND	FANTOM G7	Keyboard	GK-276R	GK-76	GKB-76	G-TOUR 76	
ROLAND	FANTOM X6	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
ROLAND	FANTOM X7	Keyboard	GK-276R	GK-76	GKB-76	G-TOUR 76	
ROLAND	FANTOM X8	Keyboard	GK-288R	GK-88	GKB-88	GKC-1648	G-TOUR 88
ROLAND	FANTOM XA 61	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
ROLAND	FP-2	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
ROLAND	FP-2C	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
ROLAND	FP4BK	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
ROLAND	FP4C-BK	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
ROLAND	FP4C-WT	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
ROLAND	FP4WH	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
ROLAND	FP-5	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
ROLAND	FP-5C	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
ROLAND	FP-7	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
ROLAND	G-1000	Keyboard	GK-276R	GK-76	GKB-76	G-TOUR 76	
ROLAND	G-70	Keyboard	GK-276-DEEP	GK-76	GKB-76		
ROLAND	GR20	Digital Audio Gear	G-MIX-B 1515	G-TOUR 12X17			
ROLAND	GR20S	Digital Audio Gear	G-MIX-B 1515	G-TOUR 12X17			
ROLAND	GR-33	Digital Audio Gear	GK-2110	G-MIX 12X24	G-MIX-B 1815	G-MIX-L 1618	G-MIX-L 1622
ROLAND	GW-7	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
ROLAND	GW8	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
ROLAND	JUNO D 61	Keyboard	GK-261R	GK-4212	G-TOUR 61		
ROLAND	JUNO STAGE	Keyboard	GK-276R	GK-76	GKB-76	G-TOUR 76	
ROLAND	JUNO-G	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
ROLAND	JV30	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
ROLAND	MC-307	Digital Audio Gear	GK-2110	G-MIX-B 1815	G-MIX-L 1618	G-MIX-L 1622	G-TOUR 12X17
ROLAND	MC-808	Digital Audio Gear	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618		
ROLAND	MC-909	Digital Audio Gear	G-MIX 19X21	G-MIX-B 2020	G-MIX-L 1622	G-TOUR 19X21	
ROLAND	MV-8000	Digital Audio Gear	G-MIX 20X25	G-MIX-B 2020	G-TOUR 20X25		
ROLAND	MV-8800	Digital Audio Gear	G-MIX 19X21	G-MIX-B 2020	G-TOUR 19X21		
ROLAND	PD105WT	Digital Audio Gear	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17	
ROLAND	RD-170	Keyboard	GK-288SLIM-XLNG	GK-88	GKB-88		
ROLAND	RD-300GX	Keyboard	GK-288R	GK-288SLIM-XLNG	GK-88	GKB-88	G-TOUR 88
ROLAND	RD-300SX	Keyboard	GK-288R	GK-288SLIM-XLNG	GK-88	GKB-88	G-TOUR 88
ROLAND	RD-700GX	Keyboard	GK-288R	GK-288SLIM-XLNG	GK-88	GKB-88	G-TOUR 88
ROLAND	RD-700SX	Keyboard	GK-288R	GK-288SLIM-XLNG	GK-88	GKB-88	G-TOUR 88
ROLAND	RS-50	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
ROLAND	RS-70	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
ROLAND	SH-201	Keyboard	GK-49	GKB-49			
ROLAND	SH-32	Digital Audio Gear	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
ROLAND	SP-404	Digital Audio Gear	G-MIX-B 1212				
ROLAND	SP-555	Digital Audio Gear	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
ROLAND	SP-606	Digital Audio Gear	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17	
ROLAND	SPD-S	Digital Audio Gear	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17	
ROLAND	TD-20	Digital Audio Gear	G-MIX-B 1515	G-MIX-L 1618	G-TOUR 12X17		

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
ROLAND	TD-3	Digital Audio Gear	G-MIX-B 1212				
ROLAND	V SYNTH	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
ROLAND	V SYNTH GT	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
ROLAND	VA-76	Keyboard	GK-276-DEEP	GK-276R	GK-76	GKB-76	G-TOUR 76
ROLAND	V-BASS	Digital Audio Gear	G-MIX-L 1622	G-MIX-L 1822			
ROLAND	VG-88	Digital Audio Gear	G-MIX-L 1622	G-MIX-L 1822			
ROLAND	VK-7	Keyboard	GK-276R	GK-76	GKB-76	G-TOUR 76	
ROLAND	VK8	Keyboard	GK-276R	GK-76	GKB-76	G-TOUR 76	
ROLAND	VP-550	Keyboard	GK-49	GKB-49			
ROLAND	VR760	Keyboard	GK-276-DEEP	GK-276R	GK-76	GKB-76	G-TOUR 76
ROLAND	VS-2000CD	Digital Audio Gear	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1622	G-TOUR 19X21	
ROLAND	VS-2400CD	Digital Audio Gear	G-MIX 19X21	G-MIX-B 2020	G-TOUR 19X21		
ROLAND	VS2480CD	Digital Audio Gear	G-MIX 20X25	G-MIX 20X30	G-TOUR 20X25	G-TOUR 20X30	
ROLAND	VS2480M	Digital Audio Gear	G-MIX 20X25	G-MIX 20X30	G-TOUR 20X25	G-TOUR 20X30	
ROLAND	VS-1824CD	Digital Audio Gear	G-MIX-B 2519	G-MIX-L 1622	G-MIX-L 1822		
ROLLS	RM82	Digital Audio Gear	GK-2110				
RUNCO	PL-42	LCD/Plasma	G-LCD-4647				
RUNCO	PL-42C	LCD/Plasma	G-LCD-4647				
RUNCO	PL-50C	LCD/Plasma	G-TOURLCDP50				
SAMPO	PME-42S6	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
SAMPO	PME-42V8	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
SAMPO	PME-42X6	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
SAMPO	PME-50X6	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
SAMSON	DB1500A	Speaker	G-SUB2225-24BAG				
SAMSON	MDR 624	Mixer	G-MIX-B 1212				
SAMSON	MDR10	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21	
SAMSON	MDR1064	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1818	G-MIX-L 1618	
SAMSON	MDR16	Mixer	G-MIX 20X25	G-MIX-B 2519	G-MIX-L 1724	G-TOUR 20X25	
SAMSON	MDR6	Mixer	G-MIX-B 1212	G-MIX-B 1515			
SAMSON	MDR8	Mixer	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
SAMSON	MIXPAD 12	Mixer	G-MIX-B 1515	G-TOUR 12X17			
SAMSON	MIXPAD 4	Mixer	G-MIX-B 1212				
SAMSON	MIXPAD 9	Mixer	G-MIX-B 1212	G-MIX-B 1515			
SAMSON	RS15S	Speaker	G-SUB2225-24BAG				
SAMSON	RS18S	Speaker	G-SUB2225-24BAG				
Samson	Stage 5	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
Samson	Stage 55	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
SAMSON	TM 300	Mixer	G-MIX 19X21	G-MIX-B 2118	G-MIX-B 2519	G-MIX-L 1822	G-TOUR 19X21
SAMSON	TM 500	Mixer	G-MIX 19X21	G-MIX-B 2118	G-MIX-B 2519	G-MIX-L 1822	G-TOUR 19X21
SAMSON	TXM16	Mixer	G-MIX 20X25	G-TOUR 20X25			
SAMSUNG	400CX	LCD/Plasma	G-TOURLCD-3743T				
SAMSUNG	400CXN	LCD/Plasma	G-TOURLCD-3743T				
SAMSUNG	400DX	LCD/Plasma	G-TOURLCD-3743T				
SAMSUNG	400DXN	LCD/Plasma	G-TOURLCD-3743T				
SAMSUNG	400FP-2	LCD/Plasma	G-TOURLCD-3743T				
SAMSUNG	400FPN-2	LCD/Plasma	G-TOURLCD-3743T				
SAMSUNG	400TSN-2	LCD/Plasma	G-TOURLCD-3743T				
SAMSUNG	403T	LCD/Plasma	G-LCD-4042				
SAMSUNG	460CX	LCD/Plasma	G-LCD-4647				
SAMSUNG	460CXN	LCD/Plasma	G-LCD-4647				
SAMSUNG	460DR	LCD/Plasma	G-LCD-4042	G-LCD-4647			
SAMSUNG	460DRN	LCD/Plasma	G-LCD-4042	G-LCD-4647			
SAMSUNG	460DX	LCD/Plasma	G-LCD-4647	G-TOURLCD-3743T			
SAMSUNG	460DXN	LCD/Plasma	G-LCD-4647	G-TOURLCD-3743T			
SAMSUNG	460FP-2	LCD/Plasma	G-LCD-4647				
SAMSUNG	460FPN-2	LCD/Plasma	G-LCD-4647				
SAMSUNG	460TSN-2	LCD/Plasma	G-LCD-4647				
SAMSUNG	460UT	LCD/Plasma	G-TOURLCD-3743T				
SAMSUNG	460UTN	LCD/Plasma	G-TOURLCD-3743T				
SAMSUNG	460UTN-UD	LCD/Plasma	G-TOURLCD-3743T				
SAMSUNG	520DX	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
SAMSUNG	520DXN	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
SAMSUNG	570DX	LCD/Plasma	G-TOURLCDP60				
SAMSUNG	570DXN	LCD/Plasma	G-TOURLCDP60				
SAMSUNG	HPL-5025	LCD/Plasma	G-TOURLCDP50				
SAMSUNG	HPN-4239	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
SAMSUNG	HPN5039	LCD/Plasma	G-TOURLCDP50				
SAMSUNG	HP-P4271	LCD/Plasma	G-LCD-4647				
SAMSUNG	HP-R5052	LCD/Plasma	G-TOURLCDP50				
SAMSUNG	HP-S5053	LCD/Plasma	G-TOURLCDP50				
SAMSUNG	LN22A450	LCD/Plasma	G-TOURLCDP-2023				
SAMSUNG	LN22B360	LCD/Plasma	G-TOURLCDP-2023				
SAMSUNG	LN32A550	LCD/Plasma	G-TOURLCDP-2632				
SAMSUNG	LN32B360	LCD/Plasma	G-TOURLCDP-2632				
SAMSUNG	LN40A550	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T			
SAMSUNG	LN40A650	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T			
SAMSUNG	LN40A750	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
SAMSUNG	LN40B530	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T			
SAMSUNG	LN40B550	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T			
SAMSUNG	LN40B630	LCD/Plasma	G-LCD-4042				
SAMSUNG	LN46A550	LCD/Plasma	G-LCD-4647	G-TOURLCDP50			
SAMSUNG	LN46A650	LCD/Plasma	G-LCD-4647	G-TOURLCDP50			
SAMSUNG	LN46A750	LCD/Plasma	G-TOURLCDP50				
SAMSUNG	LN46B530	LCD/Plasma	G-LCD-4647	G-TOURLCDP50			
SAMSUNG	LN46B550	LCD/Plasma	G-LCD-4647				

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
SAMSUNG	LN46B640	LCD/Plasma	G-TOURLCDP50				
SAMSUNG	LN46B650	LCD/Plasma	G-LCD-4647	G-TOURLCDP50			
SAMSUNG	LN46B750	LCD/Plasma	G-LCD-4647				
SAMSUNG	LN52A750	LCD/Plasma	G-TOURLCDLIFT52				
SAMSUNG	LN52A850	LCD/Plasma	G-TOURLCDP60				
SAMSUNG	LN52B550	LCD/Plasma	G-TOURLCDP50				
SAMSUNG	LN52B750	LCD/Plasma	G-TOURLCDP50				
SAMSUNG	LN55B640	LCD/Plasma	G-TOURLCDP60				
SAMSUNG	LNS5296D	LCD/Plasma	G-TOURLCDLIFT52				
SAMSUNG	LN-S5296D	LCD/Plasma	G-TOURLCDLIFT52				
SAMSUNG	LNT5271F	LCD/Plasma	G-TOURLCDP60				
SAMSUNG	P42H	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
SAMSUNG	P42HP	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
SAMSUNG	P50FP	LCD/Plasma	G-TOURLCDP50				
SAMSUNG	P50H	LCD/Plasma	G-TOURLCDP50				
SAMSUNG	P50HP	LCD/Plasma	G-TOURLCDP50				
SAMSUNG	PDP-42HD	LCD/Plasma	G-LCD-4647				
SAMSUNG	PDP-50VG	LCD/Plasma	G-TOURLCDP50				
SAMSUNG	PN42B450	LCD/Plasma	G-LCD-4647				
SAMSUNG	PPM 42S3	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
SAMSUNG	PPM-42M5S	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
SAMSUNG	PPM-50H2	LCD/Plasma	G-TOURLCDP50				
SAMSUNG	PPM-50H3	LCD/Plasma	G-TOURLCDP50				
SAMSUNG	PPM50M5H	LCD/Plasma	G-TOURLCDP50				
SAMSUNG	SPD-42P1	LCD/Plasma	G-LCD-4647				
SAMSUNG	SPD-50P2	LCD/Plasma	G-TOURLCDP50				
SAMSUNG	SPK-4215	LCD/Plasma	G-LCD-4647				
SAMSUNG	SPL-4225	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
SAMSUNG	SPN-4235	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
SAMSUNG	UN46B6000	LCD/Plasma	G-LCD-4647				
SAMSUNG	UN46B8000	LCD/Plasma	G-LCD-4647				
SANYO	PDP-42H1AN	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
SANYO	PDP-42WE	LCD/Plasma	G-LCD-4042	G-LCD-4647			
SANYO	PLC-SU51	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
SANYO	PLC-SW30	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONF
SANYO	PLC-SW35	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONF
SANYO	PLC-X25A	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
SANYO	PLC-XU100	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
SANYO	PLC-XU41	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
SANYO	PLC-XU47	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
SANYO	PLC-XU48	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
SANYO	PLC-XU51	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
SANYO	PLC-XU55A	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
SANYO	PLC-XU56	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
SANYO	PLC-XU58	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
SANYO	PLC-XU60	Projector	G-TOURCARRYON				
SANYO	PLC-XU73	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
SANYO	PLC-XU83	Projector	GAV-1412-R	GAV-DLX-1412R			
SANYO	PLC-XU86	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
SANYO	PLCXW55	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
SANYO	PLV-Z2	Projector	GAV-1813-UR	G-TOURCARRYON			
SELT	MPD-5010A	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
SENNHEISER	EW135G2 E835	Wireless System	GM-1W	GM-1WP	GM-2W	GM-5W	
SHARP	46D64U	LCD/Plasma	G-LCD-4647				
SHARP	AQUOS LC-32D40U	LCD/Plasma	G-TOURLCDP-2632				
SHARP	AQUOS LC-52D62U	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
SHARP	AQUOS LC52D64U	LCD/Plasma	G-TOURLCDP50				
SHARP	AQUOS LC-52D82U	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
SHARP	LC-20D30U	LCD/Plasma	G-TOURLCDP-2023				
SHARP	LC-26DV20U	LCD/Plasma	G-TOURLCDP-2632				
SHARP	LC-32SB24U	LCD/Plasma	G-TOURLCDP-2632				
SHARP	LC-37HV4U	LCD/Plasma	G-TOURLCD-3743T				
SHARP	LC-40E67U	LCD/Plasma	G-TOURLCD-3743T				
SHARP	LC-42D64U	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T			
SHARP	LC-45GD4U	LCD/Plasma	G-LCD-4647	G-TOURLCD-3743T			
SHARP	LC-45GD6U	LCD/Plasma	G-LCD-4647				
SHARP	LC-46D64U	LCD/Plasma	G-LCD-4647				
SHARP	LC46D65U	LCD/Plasma	G-LCD-4647				
SHARP	LC46D85U	LCD/Plasma	G-LCD-4647				
SHARP	LC-52D62U	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
SHARP	LC-52D64U	LCD/Plasma	G-TOURLCDP50				
SHARP	LC52D85U	LCD/Plasma	G-TOURLCDP50				
SHARP	LC-52D92U	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
SHARP	LCC4655U	LCD/Plasma	G-LCD-4647				
SHARP	LC-M3700	LCD/Plasma	G-TOURLCD-3743T				
SHARP	LC-PD50U	LCD/Plasma	G-TOURLCDP50				
SHARP	PG-A20X	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
SHARP	PG-B10S	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R		
SHARP	PG-MB60X	Projector	GAV-1412-R	GAV-1813-UR	GAV-DLX-1412R	GAV-PE-1412R	
SHARP	PN 465	LCD/Plasma	G-LCD-4647				
SHARP	PN455RU	LCD/Plasma	G-LCD-4647				
SHARP	PN465U	LCD/Plasma	G-LCD-4647				
SHARP	PN525U	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
SHARP	PN655U	LCD/Plasma	G-TOURLCDLIFT68				
SHARP	PNG655	LCD/Plasma	G-TOURLCDLIFT68				

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
SHARP	PNS525	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
SHARP	PNS655	LCD/Plasma	G-TOURLCDLIFT68				
SHARP	XR1S	Projector	GAV-20	GAV-DLX-20	G-TOURCARRYONP		
SHARP	XR1X	Projector	GAV-20	GAV-DLX-20	G-TOURCARRYONP		
SHARP	XR-30S	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R		
SHARP	XR-30X	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R		
SHARP	XR-40X	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R		
SHURE	M367	Mixer	G-MIX-B 1515	G-TOUR 12X17			
Shure	P2TRE2-H2 PSM 200	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
SHURE	PG14/PG185	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
Shure	PG14/PG30	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
SHURE	PG24/PG58	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
Shure	PG288/PG58	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
Shure	PGX14	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
Shure	PGX14 Clip-on mic	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
Shure	PGX24/Beta58	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
SHURE	PGX24/PG58	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
SHURE	PGX24/SM58	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
Shure	PSM 400	Wireless System	GM-4WR				
SHURE	SCM262	Mixer	G-MIX-B 1212				
SHURE	SCM268	Mixer	G-MIX-B 1212				
SHURE	SLX	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
SHURE	SLX Beta58	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
SHURE	SLX SM58	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
Shure	SLX Wireless Headset	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
SHURE	SLX Wireless System	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
Shure	SLX1	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
SHURE	SLX24/Beta87A	Wireless System	GM-1W	GM-1WP	GM-2W	GM-4WR	GM-5W
SM PRO AUDIO	DI4	Mixer	G-MIX-B 1212				
SM PRO AUDIO	DI8	Mixer	G-MIX-B 1212				
SOFTBOARD	501	LCD/Plasma	G-LCD-4042				
SOFTBOARD	502	LCD/Plasma	G-TOURLCDP50				
SOFTBOARD	503	LCD/Plasma	G-TOURLCDP50				
SOFTBOARD	512	LCD/Plasma	G-TOURLCD-3743T				
SOFTBOARD	513	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
SOFTBOARD	522	LCD/Plasma	G-TOURLCD-3743T				
SOFTBOARD	532	LCD/Plasma	G-LCD-4042	G-LCD-4647			
SOLDANO	4X12 SL CAB	Amp/Cabinet	G-TOUR-4X12-CAB				
SOLDANO	SLO100 HEAD	Amp/Cabinet	G-901				
SONY	40V4100	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T			
SONY	BRAVIA KDL-46V2500	LCD/Plasma	G-LCD-4647				
SONY	BRAVIA KDL-52XBR3	LCD/Plasma	G-TOURLCDP60				
SONY	BRAVIA KDL-V32XBR2	LCD/Plasma	G-TOURLCDP-2632				
SONY	DMXP01	Mixer	G-MIX-B 1212				
SONY	FWD40LX2F/B	LCD/Plasma	G-TOURLCD-3743T				
SONY	FWD40LX2F/S	LCD/Plasma	G-TOURLCD-3743T				
SONY	FWD50PX2/B	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
SONY	FWD-50PX2/B	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
SONY	FWD50PX2/S	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
SONY	FWD-50PX2/S	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
SONY	KDL-32L5000	LCD/Plasma	G-TOURLCDP-2632				
SONY	KDL-40D26	LCD/Plasma	G-TOURLCD-3743T				
SONY	KDL-40D27	LCD/Plasma	G-TOURLCD-3743T				
SONY	KDL-40D28	LCD/Plasma	G-TOURLCD-3743T				
SONY	KDL-40D30	LCD/Plasma	G-TOURLCD-3743T				
SONY	KDL-40S130	LCD/Plasma	G-TOURLCD-3743T				
SONY	KDL-40S28	LCD/Plasma	G-TOURLCD-3743T				
SONY	KDL-40S30	LCD/Plasma	G-TOURLCD-3743T				
SONY	KDL-40S5100	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T			
SONY	KDL-40T26	LCD/Plasma	G-TOURLCD-3743T				
SONY	KDL-40T28	LCD/Plasma	G-TOURLCD-3743T				
SONY	KDL-40T30	LCD/Plasma	G-TOURLCD-3743T				
SONY	KDL-40V4100	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T			
SONY	KDL40XBR6	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T			
SONY	KDL-46S2000	LCD/Plasma	G-LCD-4647				
SONY	KDL-46S4100	LCD/Plasma	G-LCD-4647	G-TOURLCDP50			
SONY	KDL-46S5100	LCD/Plasma	G-LCD-4647	G-TOURLCDP50			
SONY	KDL-46V4100	LCD/Plasma	G-LCD-4647				
SONY	KDL46V5100	LCD/Plasma	G-LCD-4647	G-TOURLCDP50			
SONY	KDL-46V5100	LCD/Plasma	G-LCD-4647	G-TOURLCDP50			
SONY	KDL-46XBR4	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
SONY	KDL-46Z4100/B	LCD/Plasma	G-LCD-4647				
SONY	KDL-52S5100	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
SONY	KDL-52V5100	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
SONY	KDL-52W3000	LCD/Plasma	G-TOURLCDLIFT52				
SONY	KDL-52XBR4	LCD/Plasma	G-TOURLCDP60				
SONY	KDL-52XBR5	LCD/Plasma	G-TOURLCDP60				
SONY	KDL-52XBR7	LCD/Plasma	G-TOURLCDLIFT52				
SONY	KDL-52XBR9	LCD/Plasma	G-TOURLCDP50				
SONY	KE42TS2U	LCD/Plasma	G-LCD-4042	G-LCD-4647			
SONY	KVL-40V300A	LCD/Plasma	G-TOURLCD-3743T				
SONY	PFM-42B1	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
SONY	PFM-42B2H	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
SONY	PFM-42B2U	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
SONY	PFM-42V1	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
SONY	PFM-42V1-B	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
SONY	PFM-42X1	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
SONY	PFM500A2WU	LCD/Plasma	G-TOURLCD-3743T				
SONY	PFM500A3WU	LCD/Plasma	G-TOURLCD-3743T				
SONY	PFM-50C1	LCD/Plasma	G-TOURLCDP50				
SONY	PFM510A2WU	LCD/Plasma	G-TOURLCD-3743T				
SONY	PSLX250H	Turntable	GDJ-1500	GDJ-2500	G-TOUR T-TABLE		
SONY	PWD-42LX1/B	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
SONY	SRP-X700	Digital Audio Gear	G-MIX 19X21	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	
SONY	SWD-50PX1-B	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
SONY	VAIO A140	Laptop	GAV-1813-UR	G-TOURCARRYON			
SONY	VAIO A250	Laptop	GAV-1813-UR	G-TOURCARRYON			
SONY	VAIO AR	Laptop	GAV-1813-UR	G-TOURCARRYON			
SONY	VAIO C	Laptop	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
SONY	VAIO FE	Laptop	GAV-1813-UR	G-TOURCARRYON			
SONY	VAIO FJ	Laptop	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYON
SONY	VAIO FS	Laptop	GAV-1813-UR	G-TOURCARRYON			
SONY	VAIO K35	Laptop	GAV-1813-UR	G-TOURCARRYON			
SONY	VAIO K37	Laptop	GAV-1813-UR	G-TOURCARRYON			
SONY	VAIO S150	Laptop	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
SONY	VAIO S360P	Laptop	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
SONY	VAIO T140P/L	Laptop	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYON
SONY	VAIO T150/L	Laptop	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYON
SONY	VAIO TX	Laptop	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYON
SONY	VAIO VGN	Laptop	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
SONY	VPL-CS7	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
SONY	VPL-CX70	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
SONY	VPL-CX75	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
SONY	VPL-CX80	Projector	GAV-1412-R	GAV-1813-UR	GAV-DLX-1412R	GAV-PE-1412R	
SONY	VPL-CX85	Projector	GAV-1412-R	GAV-1813-UR	GAV-DLX-1412R	GAV-PE-1412R	
SONY	VPL-DS100	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
SONY	VPL-ES2	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
SONY	VPL-EX1	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
SOUND DEVICES	442	Mixer	G-MIX-B 1212				
SOUND DEVICES	788T	Digital Audio Gear	G-MIX-B 1212				
SOUNDCRAFT	COMPACT 10	Mixer	G-MIX 12X24	G-MIX-B 1815			
SOUNDCRAFT	COMPACT 4	Mixer	G-MIX-B 1212	G-MIX-B 1515			
SOUNDCRAFT	EFX12	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 19X21	
SOUNDCRAFT	EFX8	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618
SOUNDCRAFT	EPM12	Mixer	G-MIX 20X25	G-MIX-B 2519	G-TOUR 20X25		
SOUNDCRAFT	FX16	Mixer	G-MIX 19X21	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	
SOUNDCRAFT	FX8	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21	
SOUNDCRAFT	GIGRAC 1000	Mixer	GPA-720				
SOUNDCRAFT	GIGRAC 1000ST	Mixer	G-TOUR 12X17				
SOUNDCRAFT	GIGRAC 600	Mixer	GPA-720				
SOUNDCRAFT	K1-8	Mixer	G-MIX 20X25	G-MIX-B 2519	G-TOUR 20X25		
SOUNDCRAFT	M 4	Mixer	G-MIX 19X21	G-MIX-B 2118	G-MIX-L 1622	G-TOUR 19X21	
SOUNDCRAFT	MFX 12	Mixer	G-MIX 19X21	G-MIX-B 2020	G-MIX-L 1622	G-TOUR 19X21	
SOUNDCRAFT	MFX12	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618	G-TOUR 19X21	
SOUNDCRAFT	MPM12 (NO SIDE PANELS)	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618	G-TOUR 19X21	
SOUNDCRAFT	MPM20	Mixer	G-MIX 20X30	G-TOUR 20X30			
SOUNDCRAFT	NOTEPAD	Mixer	G-MIX-B 1212	G-MIX-B 1515			
SOUNDCRAFT	POWERPAD	Mixer	G-MIX-B 1212	G-MIX-B 1515			
SOUNDCRAFT	SPIRIT E12	Mixer	G-MIX 19X21	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	
SOUNDCRAFT	SPIRIT E6	Mixer	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 19X21	
SOUNDCRAFT	SPIRIT E8	Mixer	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21	
SOUNDCRAFT	SPIRIT ES	Mixer	G-MIX 19X21	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	
SOUNDCRAFT	SPIRIT FX16	Mixer	G-MIX 19X21	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	
SOUNDCRAFT	SPIRIT FX8	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21	
SOUNDCRAFT	SPIRIT M12	Mixer	G-MIX 19X21	G-MIX-B 2020	G-TOUR 19X21		
SOUNDCRAFT	SPIRIT M12 (W/ SIDES)	Mixer	G-MIX 20X25	G-TOUR 20X25			
SOUNDCRAFT	SPIRIT M4	Mixer	G-MIX 19X21	G-MIX-B 2020	G-MIX-L 1622	G-TOUR 19X21	
SOUNDCRAFT	SPIRIT M8	Mixer	G-MIX 19X21	G-MIX-B 2020	G-TOUR 19X21		
SOUNDCRAFT	SPIRIT M8 (W/ SIDES)	Mixer	G-MIX 20X25	G-TOUR 20X25			
SOUNDCRAFT	SX 12	Mixer	G-MIX 19X21	G-MIX 20X25	G-MIX-B 2519	G-TOUR 19X21	G-TOUR 20X25
SOUNDCRAFT	UREI 1601	Mixer	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17		
SOUNDTECH	1604	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-B 1818	G-MIX-B 2118	G-MIX-L 1618
STANTON	C.324	CD/DVD Player	G-TOUR CD-13X17				
STANTON	C-302	CD/DVD Player	G-TOUR CD-13X17				
STANTON	C-303	CD/DVD Player	G-TOUR CD-13X17				
STANTON	C313	CD/DVD Player	G-TOUR CD-13X17				
STANTON	C314	CD/DVD Player	G-TOUR CD-13X17				
STANTON	CM-203	Mixer	G-MIX-B 1815	G-MIX-L 1618	G-MIX-L 1622		
STANTON	CM-205	Mixer	G-MIX-B 1815	G-MIX-L 1618	G-MIX-L 1622		
STANTON	M-201	Mixer	G-MIX-B 1212	G-MIX-B 1515			
STANTON	M-202	Mixer	G-MIX-B 1212	G-MIX-B 1515			
STANTON	M-303	Mixer	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17		
STANTON	M-304	Mixer	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17		
STANTON	M-505	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-L 1618	G-TOUR 12X17	
STANTON	RM-3	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17	
STANTON	RM-3S	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17	
STANTON	S.252	CD/DVD Player	G-TOUR CD-9X12				
STANTON	S-250	CD/DVD Player	G-TOUR CD-9X12				
STANTON	S300	CD/DVD Player	G-TOUR CD-9X12				
STANTON	SA-12	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17	

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
STANTON	SA-3	Mixer	G-MIX-B 1515	G-TOUR 12X17			
STANTON	SA-5	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-TOUR 12X17		
STANTON	SA-8	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-TOUR 12X17		
STANTON	SK-2	Mixer	G-MIX-B 1515	G-MIX-L 1618	G-TOUR 12X17		
STANTON	SK-2F	Mixer	G-MIX-B 1515	G-MIX-L 1618	G-TOUR 12X17		
STANTON	SK-5	Mixer	G-MIX-B 1212	G-MIX-B 1515			
STANTON	SK-6	Mixer	G-MIX-B 1515	G-MIX-L 1618	G-TOUR 12X17		
STANTON	SK-6F	Mixer	G-MIX-B 1515	G-MIX-L 1618	G-TOUR 12X17		
STANTON	SK-ONE	Mixer	G-TOUR 12X17				
STANTON	SMX-201	Mixer	G-MIX-B 1212	G-MIX-B 1515			
STANTON	SMX-211	Mixer	G-MIX-B 1212	G-MIX-B 1515			
STANTON	SMX-301	Mixer	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17		
STANTON	SMX-401	Mixer	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17		
STANTON	SMX-501	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17	
STANTON	ST-100	Turntable	GDJ-1500	GDJ-2500	G-TOUR T-TABLE		
STANTON	ST-90	Turntable	GDJ-1500	GDJ-2500	G-TOUR T-TABLE		
STANTON	STR8-100	Turntable	GDJ-1500	GDJ-2500	G-TOUR T-TABLE		
STANTON	STR8-20	Turntable	GDJ-1500	GDJ-2500	G-TOUR T-TABLE		
STANTON	STR8-30	Turntable	GDJ-1500	GDJ-2500	G-TOUR T-TABLE		
STANTON	STR8-50	Turntable	GDJ-1500	GDJ-2500	G-TOUR T-TABLE		
STANTON	STR8-60	Turntable	GDJ-1500	GDJ-2500	G-TOUR T-TABLE		
STANTON	STR8-80	Turntable	GDJ-1500	GDJ-2500	G-TOUR T-TABLE		
STANTON	STR8-90	Turntable	GDJ-1500	GDJ-2500	G-TOUR T-TABLE		
STANTON	T50	Turntable	GDJ-1500	GDJ-2500	G-TOUR T-TABLE		
STANTON	T60	Turntable	GDJ-1500	GDJ-2500	G-TOUR T-TABLE		
STANTON	T80	Turntable	GDJ-1500	GDJ-2500	G-TOUR T-TABLE		
STANTON	T90	Turntable	GDJ-1500	GDJ-2500	G-TOUR T-TABLE		
STUDIO LOGIC	SL 990XP	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
STUDIO LOGIC	VMK188	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
STUDIOLOGIC	SL161PRO	Keyboard	GK-249	GK-49	GKB-49		
STUDIOLOGIC	SL880PRO	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
STUDIOMASTER	C1	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-TOUR 12X17		
STUDIOMASTER	CSX	Mixer	G-MIX 19X21	G-MIX-B 2020	G-MIX-L 1622	G-TOUR 19X21	
STUDIOMASTER	PAX10	Speaker	GPA-600				
STUDIOMASTER	VPX12	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
STUDIOMASTER	VX12	Speaker	GPA-450-515	GPA-600	GPA-777	GPA-E15	GPA-SCVR450-515
STUDIOMASTER	VX15	Speaker	GPA-700	GPA-777			
STUDIOMASTER	VX15SUB	Speaker	GPA-700	GPA-777			
SUNN	T50C	Amp/Cabinet	G-212A	G-TOUR AMP2226	G-TOUR AMP2430		
SUZUKI	SP-37	Keyboard	GK-49	GK-61	GKB-61	GKC-1540	
SUZUKI	SP-67	Keyboard	GK-49	GK-61	GKB-61	GKC-1540	
SYLVANIA	LC320SS9	LCD/Plasma	G-TOURLCDP-2632				
TANNOY	ELLIPSE212ID	Speaker	G-SUB2225-24BAG				
TAPCO	6918S	Speaker	G-SUB2225-24BAG				
TAPCO	BLEND 6	Mixer	G-MIX-B 1212				
TAPCO	MIX100	Mixer	G-MIX-B 1212				
TAPCO	MIX120	Mixer	G-MIX-B 1212	G-MIX-B 1515			
TAPCO	MIX220FX	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17
TAPCO	MIX260FX	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-L 1618	G-TOUR 19X21	
TAPCO	MIX60	Mixer	G-MIX-B 1212				
TAPCO	TH-15A	Speaker	GPA-700	GPA-777			
TASCAM	2488	Digital Audio Gear	G-MIX-B 2519	G-MIX-L 1822			
TASCAM	2488 NEO	Mixer	G-MIX-B 2519	G-MIX-L 1822			
TASCAM	2488MKII	Digital Audio Gear	G-MIX-B 2519	G-MIX-L 1822			
TASCAM	414 MKII	Digital Audio Gear	G-MIX-B 1515	G-MIX-B 1815	G-TOUR 12X17		
TASCAM	424 MKII	Digital Audio Gear	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 19X21	
TASCAM	CD-D4000 MKII	CD/DVD Player	G-TOUR CD-13X17	G-TOUR CD-9X12			
TASCAM	CD-DJ1	Digital Audio Gear	G-MIX-B 1212				
TASCAM	DP-01	Digital Audio Gear	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618	G-MIX-L 1622	G-MIX-L 1822
TASCAM	DP01FX	Digital Audio Gear	G-MIX-B 1815	G-MIX-L 1622	G-MIX-L 1822		
TASCAM	DP-01FXCD	Digital Audio Gear	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618	G-MIX-L 1622	G-MIX-L 1822
TASCAM	DP-02	Digital Audio Gear	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17	
TASCAM	DP-02CF	Digital Audio Gear	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17	
TASCAM	DP-02FX/CD	Digital Audio Gear	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17	
TASCAM	FIREONE	Digital Audio Gear	G-MIX-B 1212				
TASCAM	FW-1082	Digital Audio Gear	G-MIX 19X21	G-MIX-B 2020	G-MIX-L 1622	G-TOUR 19X21	
TASCAM	FW-1884	Digital Audio Gear	G-MIX 20X25	G-MIX-B 2519	G-TOUR 20X25		
TASCAM	MD-301RMKII	Digital Audio Gear	GK-2110	G-MIX 12X24	G-MIX-L 1224	G-MIX-L 1622	G-MIX-L 1724
TASCAM	MF-P01	Digital Audio Gear	G-MIX-B 1212	G-TOUR 12X17			
TASCAM	P11 PRINTER	Digital Audio Gear	G-MIX-B 1212				
TASCAM	PORTA 02	Digital Audio Gear	G-MIX-B 1212	G-TOUR 12X17			
TASCAM	PORTA 02MKII	Digital Audio Gear	G-MIX-B 1212	G-TOUR 12X17			
TASCAM	US-122L	Digital Audio Gear	G-MIX-B 1212				
TASCAM	US-144	Digital Audio Gear	G-MIX-B 1212				
TASCAM	US-428	Digital Audio Gear	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17
TATUN	P42B5MT	LCD/Plasma	G-LCD-4647	G-TOURLCD-37437			
TATUN	P46T	LCD/Plasma	G-LCD-4647	G-TOURLCDP50			
TC ELECTRONIC	G-SYSTEM	Digital Audio Gear	G-MIX 12X24	G-MIX-L 1224	G-MIX-L 1622		
TC ELECTRONIC	NOVA SYSTEM	Digital Audio Gear	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
TECHNICS	SH-EX1200	Mixer	G-MIX-B 1515	G-MIX-L 1618	G-TOUR 12X17		
TECHNICS	SH-MZ1200	Mixer	G-MIX 17X18	G-MIX-B 1515	G-MIX-L 1618	G-TOUR 12X17	
TECHNICS	SL1210M5G	Turntable	GDJ-2500				
THOMSON	42HT93PU	LCD/Plasma	G-LCD-4647				
THOMSON	42WS90E3	LCD/Plasma	G-LCD-4647				
THOMSON	42WS93E	LCD/Plasma	G-LCD-4647				

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
TL AUDIO	FAT TRACK	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618		
TONE KING	COMET 40B	Amp/Cabinet	G-TOUR AMP2430				
TOPAZ	S18-4	Mixer	G-MIX 19X21	G-MIX-B 2020	G-MIX-L 1724	G-TOUR 19X21	
TOSHIBA	22AV600U	LCD/Plasma	G-TOURLCDP-2023				
TOSHIBA	22LV505	LCD/Plasma	G-TOURLCDP-2023				
TOSHIBA	32AV502U	LCD/Plasma	G-TOURLCDP-2632				
TOSHIBA	40RV525U	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T			
TOSHIBA	40XV645U	LCD/Plasma	G-LCD-4042	G-TOURLCD-3743T			
TOSHIBA	42WP27B	LCD/Plasma	G-TOURLCD-3743T				
TOSHIBA	46XV645U	LCD/Plasma	G-LCD-4647				
TOSHIBA	47ZV650U	LCD/Plasma	G-TOURLCDP50				
TOSHIBA	50HP66	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
TOSHIBA	50WP27B	LCD/Plasma	G-TOURLCDP50				
TOSHIBA	52HL167	LCD/Plasma	G-TOURLCDLIFT52				
TOSHIBA	52LX177	LCD/Plasma	G-TOURLCDLIFT52				
TOSHIBA	PORTEGE R100	Laptop	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
TOSHIBA	QOSMIO G20	Laptop	GAV-1813-UR	G-TOURCARRYON			
TOSHIBA	SATELLITE M35X	Laptop	GAV-1813-UR	G-TOURCARRYON			
TOSHIBA	SATELLITE 2435-S255	Laptop	GAV-1412-R	GAV-1813-UR	GAV-DLX-1412R	GAV-PE-1412R	
TOSHIBA	SATELLITE A105	Laptop	GAV-1813-UR	G-TOURCARRYON			
TOSHIBA	SATELLITE A25	Laptop	GAV-1412-R	GAV-1813-UR	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONP
TOSHIBA	SATELLITE A45	Laptop	GAV-1412-R	GAV-1813-UR	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONP
TOSHIBA	SATELLITE A75	Laptop	GAV-1813-UR	G-TOURCARRYON			
TOSHIBA	SATELLITE M35	Laptop	GAV-1813-UR	G-TOURCARRYON			
TOSHIBA	SATELLITE P25	Laptop	GAV-1813-UR	G-TOURCARRYON			
TOSHIBA	SATELLITE PRO M15-S405	Laptop	GAV-1412-R	GAV-1813-UR	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONP
TOSHIBA	SATELLITE R15	Laptop	GAV-1412-R	GAV-1813-UR	GAV-DLX-1412R	GAV-PE-1412R	
TOSHIBA	TDP-S20U	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R		
TOSHIBA	TDP-SW80U	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R		
TURBOSOUND	TXD115	Speaker	G-SUB2225-24BAG				
TURBOSOUND	TXD-118	Speaker	G-SUB2225-24BAG				
UNIVERSAL	42	LCD/Plasma	G-TOURLCD-3743T				
UNIVERSAL	MVP 2420	LCD/Plasma	G-TOURLCD-3743T				
VESTAX	CDX-05	Mixer	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
VESTAX	PCV-275	Mixer	G-MIX 12X24	G-MIX-L 1224			
VESTAX	PMC-007	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17	
VESTAX	PMC-05PRO III	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17	
VESTAX	PMC-05PRO SL	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17	
VESTAX	PMC-07	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17	
VESTAX	PMC-37 PRO	Mixer	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17		
VESTAX	VMC-002	Mixer	G-MIX-B 1212	G-MIX-B 1515			
VESTAX	VMC-185	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17	
VESTEX	BDT2500	Turntable	GDJ-1500				
VESTEX	HANDY TRAX	Turntable	GDJ-1500	G-TOUR T-TABLE			
VESTEX	PCV150	Mixer	G-MIX-L 1224				
VESTEX	PDX2000MK2	Turntable	GDJ-2500				
VESTEX	PDX2000MK2PRO	Turntable	GDJ-2500				
VESTEX	PDX2300	Turntable	GDJ-2500				
VESTEX	PDX2300MK2PRO	Turntable	GDJ-2500				
VESTEX	PMC06PROA	Mixer	G-TOUR 12X17				
VESTEX	PMC07PRO	Mixer	G-MIX-B 1515	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 12X17	
VESTEX	VCI-100	Turntable	GDJ-1500	G-TOUR T-TABLE			
VESTEX	VCI-300	Turntable	GDJ-1500	G-TOUR T-TABLE			
VIEWSONIC	CINE1000	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
VIEWSONIC	N2060W	LCD/Plasma	G-TOURLCDP-2023				
VIEWSONIC	N3751W	LCD/Plasma	G-LCD-4042				
VIEWSONIC	N4290P	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
VIEWSONIC	N4785P	LCD/Plasma	G-TOURLCDP50				
VIEWSONIC	PJ256D	Projector	G-TOURCARRYON				
VIEWSONIC	PJ400	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
VIEWSONIC	PJ402D	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONP	
VIEWSONIC	PJ452	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
VIEWSONIC	PJ458D	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONP	
VIEWSONIC	PJ506D	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONP
VIEWSONIC	PJ558D	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONP	
VIEWSONIC	PJ656	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R		
VIEWSONIC	PJ658	Projector	GAV-1412-R	GAV-DLX-1412R	GAV-PE-1412R		
VIEWSONIC	PJ766D	Projector	GAV-1412-R	GAV-20	GAV-DLX-1412R	GAV-DLX-20	GAV-PE-1412R
VIEWSONIC	PJ862	Projector	GAV-1412-R	GAV-1813-UR	GAV-DLX-1412R	GAV-PE-1412R	G-TOURCARRYONP
VIEWSONIC	VPW-425	LCD/Plasma	G-LCD-4042	G-LCD-4647			
VIEWSONIC	VPW-4255	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
VIEWSONIC	VPW-450WD	LCD/Plasma	G-LCD-4042	G-LCD-4647			
VIEWSONIC	VPW-505	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
VOX	AC100CPH	Amp/Cabinet	G-901	G-TOUR AMP HEAD			
VOX	AC15H1TV LTD	Amp/Cabinet	G-TOUR AMP2226				
VOX	AC15H1TVL	Amp/Cabinet	G-TOUR AMP2226				
VOX	AC15HTVH	Amp/Cabinet	G-112-ROTO	G-212-ROTO			
VOX	AC30BM	Amp/Cabinet	G-212A	G-TOUR AMP2430			
VOX	AC30CC1	Amp/Cabinet	G-TOUR AMP2226				
VOX	AC30CC2	Amp/Cabinet	G-212A	G-TOUR AMP2430			
VOX	AC30CC2X	Amp/Cabinet	G-212A	G-TOUR AMP2430			
VOX	AC30CCH	Amp/Cabinet	G-212-ROTO	G-901			
VOX	AC50CP2	Amp/Cabinet	G-212A	G-TOUR AMP2430			
VOX	AD100VT	Amp/Cabinet	G-212A	G-TOUR AMP2430			
VOX	AD120VTH	Amp/Cabinet	G-212A	G-TOUR AMP2430			

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
VOX	AD120VTX NEODOG	Amp/Cabinet	G-212A	G-TOUR AMP2430			
VOX	AD212	Amp/Cabinet	G-212A	G-TOUR AMP2430			
VOX	AD50VT	Amp/Cabinet	G-TOUR AMP2226				
VOX	AD60VTX NEODOG	Amp/Cabinet	G-TOUR AMP2226				
VOX	TONELAB	Digital Audio Gear	G-TOUR 12X17				
VOX	TONELAB LE	Digital Audio Gear	GK-2110	G-MIX 12X24	G-MIX-L 1224		
VOX	V112HTV	Amp/Cabinet	G-TOUR AMP2226				
VOX	V212BN	Amp/Cabinet	G-212A	G-TOUR AMP2430			
VOX	V212BNX	Amp/Cabinet	G-212A	G-TOUR AMP2430			
VOX	V412BK	Amp/Cabinet	G-TOUR-4X12-CAB				
VOX	V412BN	Amp/Cabinet	G-TOUR-4X12-CAB				
WESTINGHOUSE	LTV-20V4	LCD/Plasma	G-TOURLCDP-2023				
WESTINGHOUSE	LTV-32W4	LCD/Plasma	G-TOURLCDP-2632				
WESTINGHOUSE	TX-52F480S	LCD/Plasma	G-TOURLCDLIFT52				
WESTINGHOUSE	VM-47F140S	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
WHARFEDALE	LA15P	Speaker	GPA-700				
WHARFEDALE	LA15PB	Speaker	GPA-700				
WHARFEDALE	R-1604FX	Digital Audio Gear	G-MIX 17X18	G-MIX-B 1515	G-MIX-B 1815	G-MIX-B 1818	G-MIX-L 1618
WHARFEDALE	R-2004FX	Digital Audio Gear	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618	G-TOUR 19X21	
WHARFEDALE	SW380	Speaker	G-SUB2225-24BAG				
WHARFEDALE	TITAN 12	Speaker	GPA-450-515	GPA-600	GPA-E15	GPA-SCVR450-515	
WHARFEDALE	TITAN 15	Speaker	GPA-700				
WILLIAMS	ENCORE	Keyboard	GK-288SLIM-XLNG	GK-88	GKB-88		
YAMAHA	01V	Mixer	G-MIX 20X25	G-MIX-B 2519	G-MIX-L 1822	G-TOUR 20X25	
YAMAHA	01V96	Mixer	G-MIX 20X25	G-MIX-B 2519	G-MIX-L 1822	G-TOUR 20X25	
YAMAHA	01V96VCM	Mixer	G-MIX 20X25	G-MIX-B 2519	G-MIX-L 1822	G-TOUR 20X25	
YAMAHA	01X	Digital Audio Gear	G-MIX 19X21	G-MIX-B 1818	G-MIX-L 1618	G-TOUR 19X21	
YAMAHA	A12M	Speaker	GPA-450-515	GPA-600	GPA-700	GPA-777	GPA-SCVR450-515
YAMAHA	A15	Speaker	GPA-700				
YAMAHA	A15W	Speaker	G-SUB2225-24BAG				
YAMAHA	AW1600	Digital Audio Gear	G-MIX 19X21	G-MIX-B 1815	G-MIX-L 1622	G-TOUR 19X21	
YAMAHA	AW16G	Digital Audio Gear	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618		
YAMAHA	AW2400	Mixer	G-MIX 20X25	G-TOUR 20X25			
YAMAHA	AW4416HDCD	Digital Audio Gear	G-MIX 20X25	G-MIX-B 2519	G-TOUR 20X25		
YAMAHA	BR10	Speaker	GPA-600				
YAMAHA	BR12	Speaker	GPA-450-515	GPA-600	GPA-700	GPA-777	GPA-SCVR450-515
YAMAHA	BR12M	Speaker	GPA-450-515	GPA-600	GPA-700	GPA-777	GPA-SCVR450-515
YAMAHA	BR15	Speaker	GPA-700				
YAMAHA	BR15M	Speaker	GPA-700				
YAMAHA	C112V	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
YAMAHA	C115V	Speaker	GPA-700				
YAMAHA	CM10V	Speaker	GPA-450-515	GPA-600	GPA-E15	GPA-SCVR450-515	
YAMAHA	CM12V	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
YAMAHA	CM15V	Speaker	GPA-700				
YAMAHA	CP300	Keyboard	GKC-1648				
YAMAHA	CP33	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
YAMAHA	DD65	Digital Audio Gear	G-MIX 20X25	G-MIX-B 2519	G-TOUR 20X25		
YAMAHA	DG-60	Amp/Cabinet	G-TOUR AMP2226				
YAMAHA	DG-80	Amp/Cabinet	G-TOUR AMP2226				
YAMAHA	DGX203	Keyboard	GK-276R	GK-76	GKB-76	G-TOUR 76	
YAMAHA	DGX305	Keyboard	GK-276-DEEP				
YAMAHA	DGX505	Keyboard	GKC-1648				
YAMAHA	DJX 203	Keyboard	GK-61	GKB-61	GKC-1540		
YAMAHA	EMX 212S	Mixer	GPA-720				
YAMAHA	EMX 312S	Mixer	GPA-720				
YAMAHA	EMX 312SC	Mixer	GPA-720				
YAMAHA	EMX 5014C	Mixer	G-MIX 19X21	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	
YAMAHA	EMX 5016CF	Mixer	G-MIX 19X21	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	
YAMAHA	EMX 512S	Mixer	GPA-720				
YAMAHA	EMX 512SC	Mixer	GPA-720				
YAMAHA	EMX 620	Mixer	GPA-720				
YAMAHA	EMX 640	Mixer	GPA-720				
YAMAHA	EMX 860ST	Mixer	GPA-720				
YAMAHA	EMX2000	Mixer	G-MIX 19X21	G-MIX-B 2020	G-MIX-L 1822	G-TOUR 19X21	
YAMAHA	EMX3000	Mixer	G-MIX 19X21	G-MIX-B 2020	G-MIX-L 1822	G-TOUR 19X21	
YAMAHA	EMX5000	Mixer	G-MIX 20X25	G-MIX-B 2519	G-TOUR 20X25		
YAMAHA	EMX5000-12	Mixer	G-MIX 20X25	G-MIX-B 2519	G-TOUR 20X25		
YAMAHA	EMX62M	Mixer	GPA-720				
YAMAHA	EMX66M	Mixer	GPA-720				
YAMAHA	EMX68S	Mixer	GPA-720				
YAMAHA	EMX88S	Mixer	GPA-720				
YAMAHA	EZ150	Keyboard	GK-49				
YAMAHA	EZ200	Keyboard	GK-49	GK-61	GKB-61	GKC-1540	
YAMAHA	EZ250I	Keyboard	GK-49				
YAMAHA	GF12/12	Mixer	G-MIX 20X25	G-TOUR 20X25			
YAMAHA	GF16/12	Mixer	G-TOUR 20X30				
YAMAHA	KX25	Keyboard	GK-2110				
YAMAHA	KX49	Keyboard	GK-249	GK-49	GKB-49		
YAMAHA	KX61	Keyboard	GK-49	GKB-49			
YAMAHA	KX8	Keyboard	GKB-88				
YAMAHA	MD4S	Digital Audio Gear	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618	G-TOUR 19X21	
YAMAHA	MD8	Digital Audio Gear	G-MIX 19X21	G-MIX-B 2020	G-MIX-L 1822	G-TOUR 19X21	
YAMAHA	MG10/2	Mixer	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
YAMAHA	MG102C	Mixer	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
YAMAHA	MG12/4	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618		

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
YAMAHA	MG12/4 FX	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618		
YAMAHA	MG124C	Mixer	G-MIX 19X21	G-MIX-B 2020	G-TOUR 19X21		
YAMAHA	MG124CX	Mixer	G-MIX 19X21	G-MIX-B 2020	G-TOUR 19X21		
YAMAHA	MG16/4	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21	
YAMAHA	MG16/6FX	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1822	G-TOUR 19X21	
YAMAHA	MG166C	Mixer	G-MIX 19X21	G-MIX-B 2020	G-TOUR 19X21		
YAMAHA	MG206C-USB	Mixer	G-MIX 19X21	G-MIX-B 2020	G-TOUR 19X21		
YAMAHA	MG32/14FX	Mixer	G-MIX 22X46				
YAMAHA	MG8/2FX	Mixer	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
YAMAHA	MG82CX	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 19X21	
YAMAHA	MM1242	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618		
YAMAHA	MM1402	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618	G-TOUR 19X21	
YAMAHA	MM6	Keyboard	GK-49	GK-61	GKB-61	GKC-1540	
YAMAHA	MM8	Keyboard	GKB-88				
YAMAHA	MO6	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
YAMAHA	MO8	Keyboard	GK-288R	G-TOUR 88			
YAMAHA	MOTIF ES6	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
YAMAHA	MOTIF ES7	Keyboard	GK-276-DEEP	GK-276R	GK-76	GKB-76	G-TOUR 76
YAMAHA	MOTIF ES8	Keyboard	GK-288R	GKC-1648	G-TOUR 88		
YAMAHA	MOTIF XS6	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
YAMAHA	MOTIF XS7	Keyboard	GK-276-DEEP	GK-276R	GK-76	GKB-76	G-TOUR 76
YAMAHA	MOTIF XS8	Keyboard	GK-288R	GKC-1648	G-TOUR 88		
YAMAHA	MOTIF6	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
YAMAHA	MOTIF8	Keyboard	GK-288R	GKC-1648	G-TOUR 88		
YAMAHA	MSR250	Speaker	GPA-450-515	GPA-600	GPA-E15	GPA-SCVR450-515	
YAMAHA	MSR400	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
YAMAHA	MSR800W	Speaker	G-SUB2225-24BAG				
YAMAHA	MV12/6	Mixer	GPA-720				
YAMAHA	MV1602	Mixer	GPA-720				
YAMAHA	MW10 USB	Mixer	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17		
YAMAHA	MW12 USB	Mixer	G-MIX 17X18	G-MIX-B 1815	G-MIX-L 1618		
YAMAHA	MX12/4	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618	G-TOUR 19X21	
YAMAHA	MX12/6	Mixer	G-MIX 17X18	G-MIX-B 1818	G-MIX-L 1618	G-TOUR 19X21	
YAMAHA	MX20/6	Mixer	G-MIX 20X30	G-TOUR 20X30			
YAMAHA	MX200-12	Mixer	G-MIX 20X25	G-MIX-B 2519	G-TOUR 20X25		
YAMAHA	MX200-16	Mixer	G-MIX 20X30	G-TOUR 20X30			
YAMAHA	MX200-8	Mixer	G-MIX 19X21	G-MIX-B 2020	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21
YAMAHA	N8	Mixer	G-MIX 19X21	G-MIX-B 2118	G-MIX-L 1822	G-TOUR 19X21	
YAMAHA	NP30	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
YAMAHA	P120	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
YAMAHA	P120S	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
YAMAHA	P140	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
YAMAHA	P200	Keyboard	GK-288R	GKC-1648	G-TOUR 88		
YAMAHA	P250	Keyboard	GKC-1648				
YAMAHA	P60	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
YAMAHA	P60S	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
YAMAHA	P-70	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
YAMAHA	P85	Keyboard	GK-288SLIM	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM	
YAMAHA	P90	Keyboard	GK-288SLIM	GK-288SLIM-XLNG	GK-88 SLIM	GKB-88 SLIM	G-TOUR 88 SLIM
YAMAHA	PDM-1	LCD/Plasma	G-TOURLCDP50				
YAMAHA	PF500	Keyboard	GKC-1648				
YAMAHA	PSR-172	Keyboard	GK-49				
YAMAHA	PSR-273	Keyboard	GK-49				
YAMAHA	PSR-293	Keyboard	GK-61	GKB-61	GKC-1540		
YAMAHA	PSR-3000	Keyboard	GK-61	GKB-61	GKC-1540		
YAMAHA	PSR-E203	Keyboard	GK-49	GK-61	GKB-61	GKC-1540	
YAMAHA	PSR-E213	Keyboard	GK-49	GK-61	GKB-61	GKC-1540	
YAMAHA	PSR-E303	Keyboard	GK-49	GK-61	GKB-61	GKC-1540	
YAMAHA	PSR-E313	Keyboard	GK-49				
YAMAHA	PSR-E403	Keyboard	GK-61	GKB-61	GKC-1540		
YAMAHA	PSR-E413	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
YAMAHA	PSR-OR700	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
YAMAHA	PSR-S500	Keyboard	GK-61	GKB-61	GKC-1540		
YAMAHA	PSR-S550BK	Keyboard	GK-61	GKB-61	GKC-1540		
YAMAHA	PSR-S700	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
YAMAHA	PSR-S900	Keyboard	GK-261R	GK-61	GKB-61	GKC-1540	G-TOUR 61
YAMAHA	RADIAS-R	Mixer	G-MIX 12X24	G-MIX-L 1224			
YAMAHA	S03	Keyboard	GK-261R	GK-4212	G-TOUR 61		
YAMAHA	S08	Keyboard	GK-88	GKB-88			
YAMAHA	S112V	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
YAMAHA	S115V	Speaker	GPA-700				
YAMAHA	S90	Keyboard	GK-288R	G-TOUR 88			
YAMAHA	S90ES	Keyboard	GK-288R	G-TOUR 88			
YAMAHA	SM12V	Speaker	GPA-450-515	GPA-700	GPA-777	GPA-SCVR450-515	
YAMAHA	SM15V	Speaker	GPA-700				
YAMAHA	STAGEPAS 250M	Speaker	GPA-450-515	GPA-600	GPA-E15	GPA-SCVR450-515	
YAMAHA	STAGEPAS 500	Speaker	GPA-450-515	GPA-600	GPA-E15	GPA-SCVR450-515	
YAMAHA	TYROS	Keyboard	GK-276-DEEP				
YAMAHA	YPG225	Keyboard	GK-276-DEEP	GK-276R	GK-76	GKB-76	G-TOUR 76
YAMAHA	YPG-235	Keyboard	GK-276-DEEP	GK-276R	GK-76	GKB-76	G-TOUR 76
YAMAHA	YPG525	Keyboard	GK-88	GKB-88			
YAMAHA	YPG625	Keyboard	GK-288R	GK-88	GKB-88	GKC-1648	G-TOUR 88
YAMAHA	YPT-310	Keyboard	GK-49	GK-61	GKB-61	GKC-1540	
YAMAHA	YPT-400	Keyboard	GK-61	GKB-61	GKC-1540		
YORKVILLE	AP818	Mixer	G-MIX 20X25	G-MIX 20X30	G-MIX-B 2519	G-TOUR 20X25	G-TOUR 20X30

Gator Cases Master Cross Reference Updated 06/30/09

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
YORKVILLE	MAX16	Mixer	G-MIX 20X30	G-TOUR 20X30			
ZENITH	P42W22B	LCD/Plasma	G-LCD-4647	G-TOURLCD-3743T			
ZENITH	P42W24B/P	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
ZENITH	P42W34/34H	LCD/Plasma	G-LCD-4042	G-LCD-4647	G-TOURLCD-3743T		
ZENITH	P42W46X	LCD/Plasma	G-LCD-4647	G-TOURLCD-3743T			
ZENITH	P50W28B	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
ZENITH	P50W38/38H	LCD/Plasma	G-TOURLCDLIFT52	G-TOURLCDP50			
ZOOM	MRS1044	Digital Audio Gear	GK-2110	G-MIX-B 1815	G-MIX-L 1618	G-MIX-L 1622	G-TOUR 12X17
ZOOM	MRS1608CD	Digital Audio Gear	G-MIX 19X21	G-MIX-B 2020	G-MIX-L 1822	G-TOUR 19X21	
ZOOM	MRS4B	Digital Audio Gear	G-MIX-B 1212				
ZOOM	MRS-8	Digital Audio Gear	G-MIX-B 1212	G-TOUR 12X17			
ZOOM	MRS802BCD	Digital Audio Gear	G-MIX-B 1815	G-MIX-L 1618	G-MIX-L 1622	G-TOUR 12X17	
ZOOM	RT223	Digital Audio Gear	G-MIX-B 1212				
ZOOM	SB246	Digital Audio Gear	G-MIX-B 1212				

This list is intended as a guide; not a substitute for testing the actual fit of an instrument. All product information referenced above is based on the manufacturer's published specifications. These specifications may change over time and without notice. If you have questions on a specific case or product, or see that a correction is needed, please contact Gator Customer Service at 813.221.4191 or send us an email at info@gatorcases.com.

Gator Cases Cross Reference

- Interior Case Dimensions -

Standard

Keyboard Cases

Model	Length	Width	Height
GK-2110	22.5	11	4
GK-249	38	15	5.5
GK-261R	44	17.25	6
GK-276R	51.25	18	6
GK-276-Deep	51.25	20	8
GK-288 Slim	54	15	6
GK-288 Slim-XLNG	59	15	6
GK-288R	59	19	6.5
GK-49	38	15	5.5
GK-61	43	17.5	6.5
GK-76	51.5	18	6.5
GK-88	57.5	18	6
GK-88 SL	54	15	6
G-TOUR-61	44	17.38	6
G-TOUR-76	51.25	18	6
G-TOUR-88	59	19	6.63
G-TOUR-88 SL	54	15	6

Mixer Cases

Model	Length	Width	Height
G-MIX 12 x 24	23.25	12	4.25
G-MIX 17 x 18	17.75	17.25	6.5
G-MIX 19 x 21	21	19	7.5
G-MIX 20 X 25	25	20	8
G-MIX 20 x 30	30	20	6.25
G-MIX 22 x 46	46	22	6.5
G-MIX 24 x 36	36	24	5.5
G-MIX-B 1212	12	12	4
G-MIX-B 1515	15	15	5.5
G-MIX-B 1815	18.5	15	6.5
G-MIX-B 1818	18	18	5.5
G-MIX-B 2118	21	18.5	7
G-MIX-B 2519	25	19	8
G-MIX-B 2020	20	20	5.5
G-MIX-L 1224	24	11.75	5
G-MIX-L 1618	18	16	6
G-MIX-L 1622	22	16	5.5
G-MIX-L 1822	22	18	7.5
G-TOUR 12 x 17	17	12	7.5
G-TOUR 19 x 21	21	19	7
G-TOUR 20 x 25	25	20	8
G-TOUR 20 x 30	30	20	6.25
G-TOUR 24 x 36	36	24	5.5
GPA-720	20	13.5	13

Laptop/Gear Cases

Model	Length	Width	Height
GAV-1412R (gear compartment) <i>Fits Laptops up to 14" x 12"</i>	14	12	4
GAV-1813R (gear compartment) <i>Fits Laptops up to 18" x 13"</i>	18	13	4
GAV-20 (gear compartment) <i>Fits Laptops up to 14" x 10.5"</i>	15	11	6
GAV-DLX-1412R (gear compartment) <i>Fits Laptops up to 14" x 12"</i>	14	12	4
GAV-DLX-20 (gear compartment) <i>Fits Laptops up to 14" x 10.5"</i>	15	11	6
GAV-PE-1412R (gear compartment) <i>Fits Laptops up to 14" x 12"</i>	14	12	4

Amp Cases

Model	Length	Width	Height
G-112	25	19.5	12
G-212	30	23.25	12
G-901	30	12.5	10.5
GPA-720	20	13.5	13
G-112-ROTO	23.5	12.5	16
G-212-ROTO	26.8	12.5	16
G-TOUR 4x12 CAB	32	32	17
G-TOUR-AMP 2226	26	22	13
G-TOUR-AMP 2430	30	24	13
G-TOUR AMP HEAD	32	14	12

Gator Cases Cross Reference

- Interior Case Dimensions -

Metric

Keyboard Cases

Model	Length	Width	Height
GK-2110	562.5	275	100
GK-249	950	375	137.5
GK-261R	1100	431.25	150
GK-276R	1281.25	450	150
GK-276-Deep	1281.25	500	200
GK-288 Slim	1350	375	150
GK-288 Slim-XLNG	1475	375	150
GK-288R	1475	475	162.5
GK-49	950	375	137.5
GK-61	1075	437.5	162.5
GK-76	1287.5	450	162.5
GK-88	1437.5	450	150
GK-88 SL	1350	375	150
G-TOUR-61	1100	434.5	150
G-TOUR-76	1281.25	450	150
G-TOUR-88	1475	475	165.75
G-TOUR-88 SL	1350	375	150

Mixer Cases

Model	Length	Width	Height
G-MIX 12 x 24	581.25	300	106.25
G-MIX 17 x 18	443.75	431.25	162.5
G-MIX 19 x 21	525	475	187.5
G-MIX 20 X 25	625	500	200
G-MIX 20 x 30	750	500	156.25
G-MIX 22 x 46	1150	550	162.5
G-MIX 24 x 36	900	600	137.5
G-MIX-B 1212	300	300	100
G-MIX-B 1515	375	375	137.5
G-MIX-B 1815	462.5	375	162.5
G-MIX-B 1818	450	450	137.5
G-MIX-B 2118	525	462.5	175
G-MIX-B 2519	625	475	200
G-MIX-B 2020	500	500	137.5
G-MIX-L 1224	600	293.75	125
G-MIX-L 1618	450	400	150
G-MIX-L 1622	550	400	137.5
G-MIX-L 1822	550	450	187.5
G-TOUR 12 x 17	425	300	187.5
G-TOUR 19 x 21	525	475	175
G-TOUR 20 x 25	625	500	200
G-TOUR 20 x 30	750	500	156.25
G-TOUR 24 x 36	900	600	137.5
GPA-720	500	337.5	325

Laptop/Gear Cases

Model	Length	Width	Height
GAV-1412R (gear compartment) <i>Fits Laptops up to 350 x 300</i>	350	300	100
GAV-1813R (gear compartment) <i>Fits Laptops up to 450 x 325</i>	450	325	100
GAV-20 (gear compartment) <i>Fits Laptops up to 350 x 262.5</i>	375	275	150
GAV-DLX-1412R (gear compartment) <i>Fits Laptops up to 350 x 300</i>	350	300	100
GAV-DLX-20 (gear compartment) <i>Fits Laptops up to 350 x 262.5</i>	375	275	150
GAV-PE-1412R (gear compartment) <i>Fits Laptops up to 350 x 300</i>	350	300	100

Amp Cases

Model	Length	Width	Height
G-112	625	487.5	300
G-212	750	581.25	300
G-901	750	312.5	262.5
GPA-720	500	337.5	325
G-112-ROTO	587.5	312.5	400
G-212-ROTO	670	312.5	400
G-TOUR 4x12 CAB	800	800	425
G-TOUR-AMP 2226	650	550	325
G-TOUR-AMP 2430	750	600	325
G-TOUR AMP HEAD	800	350	300